



PREMIUM WIPER BLADES

Application Guide for
Passenger Cars & Light Trucks
2013

LIQUID ARMOR PERFORMANCE





TABLE OF CONTENTS

AM General	4
Acura	4
Alfa Romeo.....	4
Alfa Romeo.....	5
American Motors.....	5
Aston Martin.....	5
Audi.....	5
Avanti.....	7
BMW	7
Buick	12
Cadillac	13
Chevrolet	14
Chrysler	20
Daewoo	21
Daihatsu.....	21
DeLorean.....	21
Dodge	21
Eagle.....	25
Fiat	25
Ford.....	25
GMC	30
Geo.....	33
Honda	34
Hummer.....	35
Hyundai	35
Infiniti	36
Isuzu	37
Jaguar	38
Jeep.....	39
Kia.....	39
Land Rover	40
Lexus	41



Lincoln	42
Lotus.....	43
Maserati	43
Mazda	44
Mercedes-Benz.....	45
Mercury	51
Merkur	52
Mini	52
Mitsubishi	52
Mitsubishi Fuso	53
Nissan	54
Oldsmobile	56
Plymouth	57
Pontiac.....	58
Porsche	59
Ram.....	60
Saab.....	60
Saturn	61
Scion	62
Smart	62
Sterling.....	62
Subaru	62
Suzuki	63
Toyota	64
Volkswagen	66
Volvo	67
Yugo.....	68



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
AM General						
Hummer						
2001-1992	12 ^D	12 ^D				
Acura						
CL						
2003-2001	24	19		24	19	
1999-1997	24	20		24	20	
CSX						
2008	26	22		26	22	
EL						
2005-2001	21	19		21	19	
2000-1999	20	18		20	18	
1998-1997	20	18	15	20	18	15
ILX						
2014-2013	26	19		26	19	
Integra						
2001-1994	22	18	19	22	18	19
1993-1990	20	19	19	20	19	19
1989-1986	18	18	18	18	18	18
Legend						
1995-1993	22	19		22	19	
1992-1986	20	19		20	19	
MDX						
2013-2007	26	21		26	21	R12-B
2006-2001	24	21	18	24	21	18
NSX						
2005-1991	22	22		22	22	
RDX						
2014-2013	26	16		26	16	R14-B
2012-2007	26 ^V	16 ^V		26 ^V	16 ^V	R14-B
RL						
2004-1996	22	19		22	19	
RLX						
2014	26	19		26	19	
RSX						
2006-2002	24	20	20	24	20	20
SLX						
1999-1998	20	20	15	20	20	15
1997	20	20	19	20	20	19
1996	20	20	15	20	20	15
TL						
2013-2004	26	19		26	19	
2003-1995	24	19		24	19	
TSX						
2013-2009	24	22		24	22	R12-A
2008-2005	24	16		24	16	
2004	26	16		26	16	
Vigor						
1994-1992	24	19		24	19	
ZDX						
2013-2010	24	19		24	19	
Alfa Romeo						
164						
1995-1991	21	21		21	21	
Berlina						
1974-1970	16	16		16	16	
GT Veloce						
1974-1971	16	16		16	16	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS						
MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Alfa Romeo						
GTV-6						
1986-1985	17	17		17	17	
1984-1981	18 °	18 °		18 °	18 °	
Milano						
1989-1987	18	18		18	18	
Spider						
1994-1985	17	17		17	17	
1984-1971	16	16		16	16	
Sport						
1979-1978	16 °	16 °		16 °	16 °	
American Motors						
AMX						
1980-1978, 1974-1970	18	18		18	18	
Ambassador						
1974-1970	16	16		16	16	
Concord						
1983-1980	18	18	16 °	18	18	16 °
1979-1978	18	18		18	18	
Eagle						
1988-1980	18	18	16 °	18	18	16 °
Gremlin						
1978	18	18		18	18	
1977-1973	16	16		16	16	
1972-1970	18	18		18	18	
Hornet						
1977-1973	16	16		16	16	
1972-1970	18	18		18	18	
Javelin						
1974-1970	18	18		18	18	
Matador						
1978-1971	16	16		16	16	
Pacer						
1979-1975	18 °	18 °	16 °	18 °	18 °	16 °
Rebel						
1970	16	16		16	16	
Spirit						
1983-1979	18	18	18 °	18	18	18 °
Aston Martin						
DB7						
2004-2000, 1998-1997	21	15		21	15	
DB9						
2009-2005	24	20		24	20	
DBS						
2009-2008	24	20		24	20	
V8 Vantage						
2009-2008	24	20		24	20	
Audi						
100						
1994-1992	22	22	18	22	22	18
1991-1989	21 ½	21 ½		21 ½	21 ½	
100 Quattro						
1994-1992	22	22	18	22	22	18
1991-1989	21 ½	21 ½		21 ½	21 ½	
200						
1991-1989	21 ½	21 ½		21 ½	21 ½	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Audi						
200 Quattro						
1991-1989	21 ^L	21 ^L		21 ^L	21 ^L	
4000						
1987-1985	21 ^L	21 ^L		21 ^L	21 ^L	
1984-1980	18	18		18	18	
4000 Quattro						
1987-1985	21 ^L	21 ^L		21 ^L	21 ^L	
1984	18	18		18	18	
5000						
1988-1984	21 ^L	21 ^L	18 ^L	21 ^L	21 ^L	18 ^L
1983-1978	18	18		18	18	
5000 Quattro						
1988-1986	21 ^L	21 ^L	18 ^L	21 ^L	21 ^L	18 ^L
80						
1992-1988	21 ^L	21 ^L		21 ^L	21 ^L	
80 Quattro						
1992-1988	21 ^L	21 ^L		21 ^L	21 ^L	
90						
1995-1993	21	21		21	21	
1991-1988	21 ^L	21 ^L		21 ^L	21 ^L	
90 Quattro						
1995-1993	21	21		21	21	
1991-1988	21 ^L	21 ^L		21 ^L	21 ^L	
A3						
2013			14	24 ^H	19 ^H	14
2012-2006			14	22 ^H	20 ^H	14
A4						
2013-2009			15	24 ^F	20 ^F	15
2001-1998	21	21	15	21	21	15
1997-1996	21	21		21	21	
A4 Quattro						
2008-2002				22 ^J	22 ^J	
2001-1998	21	21	15	21	21	15
1997-1996	21	21		21	21	
A5 Quattro						
2012-2008				24 ^F	20 ^F	
A6						
2004-2001	22	22		22	22	
2000-1995	22	22	18	22	22	18
A6 Quattro						
2004-1995	22	22	18	22	22	18
A8						
2000-1997	22	22		22	22	
A8 Quattro						
2013-2011				26 ^F	20 ^F	
2001-1997	22	22		22	22	
Allroad Quattro						
2004-2001	22	22		22	22	
Cabriolet						
1998-1994	22	22		22	22	
Coupe						
1987-1985	21 ^L	21 ^L	18	21 ^L	21 ^L	18
1984-1981	18	18		18	18	
Coupe Quattro						
1991-1990	21	21		21	21	
Fox						
1979	16	16		16	16	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Audi						
Fox						
1978-1977	16	16	16	16	16	16
1976-1973	16	16		16	16	
Q5						
2013-2009				24 ^P	20 ^P	
Q7						
2013-2007				26 ^H	26 ^H	
Quattro						
1986	21 ^L	21 ^L		21 ^L	21 ^L	
1985-1984	21 ^L	21 ^L	18	21 ^L	21 ^L	18
1983	18	18	18	18	18	18
RS4						
2008-2007	22 ^J	22 ^J		22 ^J	22 ^J	
RS6						
2004-2003			15			15
S4						
2013-2009			15			15
2001-2000	21	21		21	21	
1994-1992	22	22		22	22	
S6						
2004-2003	22	22	15	22	22	15
2002	22	22	18	22	22	18
2001, 1997-1996	22	22		22	22	
1995	22	22	18	22	22	18
S8						
2013				26 ^P	20 ^P	
2002-2001	22	22		22	22	
Super 90						
1972-1970	16	16		16	16	
TT						
2004-2000	21	21		21	21	
TT Quattro						
2013-2008				21 ^H	21 ^H	
2006-2005				21 ^Q	21 ^Q	
2004-2000	21	21		21	21	
V8 Quattro						
1994-1992	22	22		22	22	
1991-1990	21 ^L	21 ^L		21 ^L	21 ^L	
Avanti						
II						
1990-1987, 1985-1965	15 ^E	15 ^E		15 ^E	15 ^E	
BMW						
1 Series M						
2011				20 ^H	20 ^H	
118i						
2013-2012				20 ^H	20 ^H	
120i						
2012-2008				20 ^H	20 ^H	
125i						
2013, 2010-2009				20 ^H	20 ^H	
128i						
2013-2008				20 ^H	20 ^H	
130i						
2010-2008				20 ^H	20 ^H	
135i						
2013-2008				20 ^H	20 ^H	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
BMW						
135is						
2013				20 "	20 "	
318i						
1999-1992	21	20		21	20	
1991, 1985-1984	20	20		20	20	
318is						
1999	22	20		22	20	
1998-1992	21	20		21	20	
1991	20	20		20	20	
318ti						
1999	22	20	18	22	20	18
1998-1995	21	20	18	21	20	18
320i						
2005-2004				24 °	19 °	
2003-2001	22	20		22	20	
1995-1992	21	20		21	20	
1983-1980	18	18		18	18	
1979-1977	16 °	16 °		16 °	16 °	
323Ci						
2000	22	20		22	20	
323i						
2010				24 "	19 "	
2009-2006				24 °	19 °	
2001-1999	22	20		22	20	
1998-1997	21	20		21	20	
323is						
1999	22	20		22	20	
323ti						
2000-1999	22	20	18	22	20	18
325						
1988-1986	20	20		20	20	
325e						
1987-1984	20	20		20	20	
325i						
2013-2011 Coupe				24 "	18 "	
2013-2011 Sedan				24 °	19 °	
1997-1996	21	20		21	20	
1995-1994 Convertible	22	20		22	20	
1995-1992 Sedan	21	20		21	20	
1993-1992 Convertible	20	20		20	20	
1991-1987	20	20		20	20	
325iX						
1991-1988	20	20		20	20	
325is						
1995-1993	21	20		21	20	
1992-1987	20	20		20	20	
328i						
2013-2011 Coupe				24 "	18 "	
2013-2010 Sedan				24 "	19 "	
2010 Coupe				24 °	18 °	
2009-2007				24 °	19 °	
2000-1996	21	20		21	20	
328i xDrive						
2013-2010 Coupe				24 "	18 "	
2013, 2011-2010 Sedan				24 "	19 "	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
BMW						
328i xDrive						
2012 Wagon				24 ^H	19 ^H	
2009				24 ^O	19 ^O	
328is						
1999-1996	21	20		21	20	
328xi						
2008-2007				24 ^O	19 ^O	
330Ci						
2006				24 ^O	19 ^O	
2005-2004				24 ^O	18 ^O	
2003-2001	22	20		22	20	
330i						
2007-2004				24 ^O	19 ^O	
2003-2001	22	20		22	20	
330xi						
2006-2004				24 ^O	19 ^O	
2003-2001	22	20		22	20	
335d						
2011-2010				24 ^H	19 ^H	
2009				24 ^O	19 ^O	
335i						
2013-2010 Coupe				24 ^H	18 ^H	
2013-2010 Sedan				24 ^H	19 ^H	
2009-2007				24 ^O	19 ^O	
335i xDrive						
2013-2011 Coupe				24 ^H	18 ^H	
2011-2010 Sedan				24 ^H	19 ^H	
2010 Coupe				24 ^O	19 ^O	
2009				24 ^O	19 ^O	
335is						
2013-2011 Convertible				24 ^H	18 ^H	
2013-2011 Coupe				24 ^H	18 ^H	
335xi						
2008-2007				24 ^O	19 ^O	
524td						
1986-1985	18	18		18	18	
525i						
2010-2004				24 ^H	22 ^H	
2003-2001	LR-26 ^X	LR-21 ^X				
1995-1989	22	24		22	24	
525xi						
2007-2006				24 ^H	22 ^H	
528e						
1988-1982	18	18		18	18	
528i						
2013-2011				26 ^O	18 ^O	
2010-2008				24 ^H	22 ^H	
2000-1997	LR-26 ^X	LR-21 ^X				
1981-1979	18	18		18	18	
528i xDrive						
2013-2012				26 ^O	18 ^O	
2010-2009				24 ^H	22 ^H	
528xi						
2008				24 ^H	22 ^H	
530i						
2013-2012				26 ^O	18 ^O	
2010-2004				24 ^H	22 ^H	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
BMW						
530i						
2003-2001	LR-26 ^x	LR-21 ^x				
1995-1994				22 ^h	24 ^h	
530xi						
2007-2006				24 ^h	22 ^h	
533i						
1984-1983	18	18		18	18	
535i						
2013-2011				26 ^o	18 ^o	
2010-2008				24 ^h	22 ^h	
1993-1989				22 ^h	24 ^h	
1988-1985	18	18		18	18	
535i GT						
2013-2011				26 ^o	18 ^o	
2010			15	24 ^o	22 ^o	15
535i GT xDrive						
2013-2011				26 ^o	18 ^o	
535i xDrive						
2013-2011				26 ^o	18 ^o	
2010-2009				24 ^h	22 ^h	
535is						
1988	18	18		18	18	
535xi						
2008				24 ^h	22 ^h	
540i						
2003-1997	LR-26 ^x	LR-21 ^x				
1995-1994				22 ^h	24 ^h	
545i						
2006-2004				24 ^h	22 ^h	
550i						
2013-2011				26 ^o	18 ^o	
2010-2006				24 ^h	22 ^h	
550i GT						
2013-2011				26 ^o	18 ^o	
2010			15	24 ^h	22 ^h	15
550i GT xDrive						
2013-2011				26 ^o	18 ^o	
2010			15	24 ^h	22 ^h	15
550i xDrive						
2013-2011				26 ^o	18 ^o	
633CSi						
1984-1979	18	18		18	18	
635CSi						
1989-1985	18	18		18	18	
640i						
2014-2012				26 ^o	17 ^o	
640i Gran Coupe						
2014-2013				26 ^o	17 ^o	
640i xDrive						
2014				26 ^o	17 ^o	
640i xDrive Gran Coupe						
2014				26 ^o	17 ^o	
645Ci						
2005-2004				24 ^h	22 ^h	
650Ci						
2011				26 ^o	17 ^o	
2009-2006				24 ^h	22 ^h	
650i						
2014-2012				26 ^o	17 ^o	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
BMW						
650i						
2010-2006				24 "H	22 "H	
650i Gran Coupe						
2014-2013				26 "Q	17 "Q	
650i Gran Coupe xDrive						
2013				26 "Q	17 "Q	
650i xDrive						
2014-2013				26 "Q	17 "Q	
2012	26 "Q	17 "Q		26 "Q	17 "Q	
650i xDrive Gran Coupe						
2014				26 "Q	17 "Q	
733i						
1984-1979	18	18		18	18	
735i						
1992-1988				22 "H	24 "H	
1987-1985	18	18		18	18	
735iL						
1992-1988				22 "H	24 "H	
740Li						
2013-2011				26 "Q	19 "Q	
740Li xDrive						
2013				26 "Q	19 "Q	
740i						
2013-2010				26 "Q	19 "Q	
2001-1997, 1995-1993	22	24		22	24	
740iL						
2001-1993	22	24		22	24	
745Li						
2005-2002				26 "Q	19 "Q	
745i						
2005-2002				26 "Q	19 "Q	
750Li						
2013-2006				26 "Q	19 "Q	
750Li xDrive						
2013-2010				26 "Q	19 "Q	
750i						
2013-2006				26 "Q	19 "Q	
750i xDrive						
2013-2010				26 "Q	19 "Q	
750iL						
2001-1993	22	24		22	24	
760Li						
2013-2003				26 "Q	19 "Q	
760i						
2006-2004				26 "Q	19 "Q	
M3						
2012-2011				24 "H	18 "H	
2010-2008, 2006				24 "Q	19 "Q	
2005-2004				24 "Q	18 "Q	
2003				22	20	
2002-2001	22	19		22	19	
1999-1994	21	20		21	20	
1991-1988	20	20		20	20	
M5						
2011-2006				24 "H	22 "H	
2003-2000				26 "U	22 "U	
1993-1991	22	24		22	24	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS						
MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
BMW						
M5						
1988	20	18		20	18	
M6						
2011-2006				24 ^H	22 ^H	
1988-1987	18	18		18	18	
X1						
2014-2013				24 ^H	18 ^H	
X3						
2014-2011				26 ^Q	20 ^Q	
2010-2004	22	20		22	20	
X5						
2013			15 ^U	24 ^F	20 ^F	15 ^U
2012			15 ^U	24 ^{AO}	20 ^{AO}	15 ^U
2012				24 ^{BF}	20 ^{BF}	
2011-2008				24 ^Q	20 ^Q	
2007-2000	24	22	18	24	22	18
X6						
2013				24 ^F	20 ^F	
2012-2008				24 ^Q	20 ^Q	
Z3						
2002-1996	20	20		20	20	
Z4						
2013	21	20		21	20	
2012	22	20		22	20	
2011-2003	21	20		21	20	
Buick						
Allure						
2009-2005	22	22		22	22	
Century						
2005-1997	22	22		22	22	
1996-1984	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
1981-1978	18 ^D	18 ^D		18 ^D	18 ^D	
Commercial Chassis						
1996-1991	22	22	16	22	22	16
Electra						
1990-1985	19 ^D	19 ^D		19 ^D	19 ^D	
Enclave						
2013				24 ^H	21 ^H	R12-E
2012				24 ^H	22 ^H	R12-E
2011-2008				24 ^F	21 ^F	R12-E
Encore						
2013				26 ^F	14 ^F	
Estate Wagon						
1989-1988, 1983-1970	18 ^D	18 ^D		18 ^D	18 ^D	
LaCrosse						
2013-2010	26	18		26	18	
2009-2005	22	22		22	22	
LeSabre						
2005-1997	22	22		22	22	
1996-1992	22 ^N	22 ^N		22 ^N	22 ^N	
1991-1986	19 ^D	19 ^D		19 ^D	19 ^D	
1985-1968	18 ^D	18 ^D		18 ^D	18 ^D	
Lucerne						
2011-2006				24 ^H	21 ^H	
Park Avenue						
2005-1997	22	22		22	22	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Buick						
Park Avenue						
1996-1991	22 ^N	22 ^N		22 ^N	22 ^N	
Rainier						
2007-2006	22	22		22	22	R12-E
2005-2004	22	22	16	22	22	16
Reatta						
1991-1988	19 ^D	19 ^D		19 ^D	19 ^D	
Regal						
2013-2011	24	18		24	18	
2004-1997	22	22		22	22	
1996-1988	20 ^N	20 ^N		20 ^N	20 ^N	
1987-1978	18 ^D	18 ^D		18 ^D	18 ^D	
Rendezvous						
2007-2002	24	22	16	24	22	16
Riviera						
1999-1995	22 ^N	22 ^N		22 ^N	22 ^N	
1993-1986	19 ^D	19 ^D		19 ^D	19 ^D	
1985-1970	18 ^D	18 ^D		18 ^D	18 ^D	
Roadmaster						
1996-1991	22 ^N	22 ^N	17 ^D	22 ^N	22 ^N	17 ^D
Skyhawk						
1989-1983	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D
1982, 1980-1975	16 ^D	16 ^D		16 ^D	16 ^D	
Skylark						
1998-1986	19 ^D	19 ^D		19 ^D	19 ^D	
1985-1980	18 ^D	18 ^D		18 ^D	18 ^D	
Somerset						
1987-1986	19 ^D	19 ^D		19 ^D	19 ^D	
Somerset Regal						
1985	19 ^D	19 ^D		19 ^D	19 ^D	
Terraza						
2007-2005	24	22	16	24	22	16
Verano						
2013-2012				26 ^F	24 ^F	
Cadillac						
60 Special						
1993	22 ^N	22 ^N		22 ^N	22 ^N	
ATS						
2013	22	18		22	18	
Allante						
1993-1987	19 ^D	19 ^D		19 ^D	19 ^D	
Brougham						
1992-1991	18	18		18	18	
CTS						
2013-2008	22	19		22	19	
2007-2003	22	21		22	21	
Calais						
1976-1974	18 ^D	18 ^D		18 ^D	18 ^D	
Catera						
2001-1997	24	19		24	19	
Cimarron						
1988-1982	16 ^D	16 ^D		16 ^D	16 ^D	
Commercial Chassis						
1996-1991	22	22		22	22	
1990-1986	19	19		19	19	
1984-1975	18 ^D	18 ^D		18 ^D	18 ^D	
DTS						
2011-2006	22	22		22	22	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Cadillac						
DeVille						
2005-1991	22 ^N	22 ^N		22 ^N	22 ^N	
1990-1985	19 ^D	19 ^D		19 ^D	19 ^D	
1984-1974	18 ^D	18 ^D		18 ^D	18 ^D	
Eldorado						
2002-1992	22 ^N	22 ^N		22 ^N	22 ^N	
1991-1986	19 ^D	19 ^D		19 ^D	19 ^D	
1985-1974	18 ^D	18 ^D		18 ^D	18 ^D	
Escalade						
2013-2009	22 ^M	22 ^M		22 ^M	22 ^M	R12-E
2008	22	22		22	22	R12-E
2007				22 ^H	22 ^H	R12-E
2006-2002	22	22	16	22	22	16
2000-1999	18	18	14 ^D	18	18	14 ^D
Fleetwood						
1996-1993	22 ^N	22 ^N		22 ^N	22 ^N	
1992-1985	19 ^D	19 ^D		19 ^D	19 ^D	
1984-1974	18 ^D	18 ^D		18 ^D	18 ^D	
SRX						
2013-2010			12	26 ^F	17 ^F	12
2009-2004	22	21	12	22	21	12
STS						
2011-2005				22 ^H	21 ^H	
Seville						
2004-1998	22	22		22	22	
1997-1992	22 ^N	22 ^N		22 ^N	22 ^N	
1991-1986	19 ^D	19 ^D		19 ^D	19 ^D	
1985-1976	18 ^D	18 ^D		18 ^D	18 ^D	
XLR						
2009-2004	22	22		22	22	
XTS						
2013	26	18		26	18	
Chevrolet						
Astro						
2005-1985	18 ^D	18 ^D	14 ^D	18 ^D	18 ^D	14 ^D
Avalanche						
2013-2008	22	22		22	22	
2007				22 ^H	22 ^H	
Avalanche 1500						
2006-2002	22	22		22	22	
Avalanche 2500						
2006-2002	22	22		22	22	
Aveo						
2011-2008	22	19		22	19	
2007-2004	22	19	15	22	19	15
Aveo5						
2011-2007	22	19	15	22	19	15
Beretta						
1996-1987	19 ^D	19 ^D		19 ^D	19 ^D	
Blazer						
2005-1995	20	20	14	20	20	14
1994-1992	18 ^D	18 ^D	14 ^D	18 ^D	18 ^D	14 ^D
1991-1987	16 ^D	16 ^D		16 ^D	16 ^D	
1974-1973	16 ^E	16 ^E		16 ^E	16 ^E	
C10						
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Chevrolet						
C10						
1984-1975	16 ^E	16 ^E		16 ^E	16 ^E	
C10 Pickup						
1974-1973	16 ^E	16 ^E		16 ^E	16 ^E	
C10 Suburban						
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1973	16 ^E	16 ^E		16 ^E	16 ^E	
C1500						
1999-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
C1500 Suburban						
1999-1995	18	18	14	18	18	14
1994-1992	18 ^D	18 ^D		18 ^D	18 ^D	
C20						
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1975	16 ^E	16 ^E		16 ^E	16 ^E	
C20 Pickup						
1974-1973	16 ^E	16 ^E		16 ^E	16 ^E	
C20 Suburban						
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1973	16 ^E	16 ^E		16 ^E	16 ^E	
C2500						
2000-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
C2500 Suburban						
1999-1995	18	18	14	18	18	14
1994-1992	18 ^D	18 ^D		18 ^D	18 ^D	
C30						
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1975	16 ^E	16 ^E		16 ^E	16 ^E	
C30 Pickup						
1974-1973	16 ^E	16 ^E		16 ^E	16 ^E	
C35						
2000-1995	18	18		18	18	
C3500						
2002-2001	22	22		22	22	
2000-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
C50						
1987	16 ^D	16 ^D		16 ^D	16 ^D	
C60						
1987	16 ^D	16 ^D		16 ^D	16 ^D	
C70						
1987	16 ^D	16 ^D		16 ^D	16 ^D	
Camaro						
2013-2011	24	21		26 ^H	15 ^H	
2010	24	21		24	21	
2002-1998	24	24		24	24	
1997-1993	24-R ^O	24-R ^O				
1992-1989	18 ^D	18 ^D		18 ^D	18 ^D	
1988-1982	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
1981-1970	18 ^D	18 ^D		18 ^D	18 ^D	
Caprice						
2013-2011				26 ^H	15 ^H	
1996-1991	22 ^N	22 ^N	17 ^D	22 ^N	22 ^N	17 ^D
1990	18 ^D	18 ^D	17 ^D	18 ^D	18 ^D	17 ^D
1989-1971	18 ^D	18 ^D		18 ^D	18 ^D	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Chevrolet						
Captiva Sport						
2013-2012	24	16	11	24	16	
Cavalier						
2005-1995	22	17		22	17	
1994-1990	17 ^D	17 ^D		17 ^D	17 ^D	
1989	16 ^D	16 ^D		16 ^D	16 ^D	
1988-1982	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D
Celebrity						
1990-1984	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
Chevette						
1987-1976	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D
Citation						
1983-1980	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
Citation II						
1985-1984	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
Classic						
2005-2004	22	19		22	19	
Cobalt						
2010-2005	22	17		22	17	
Colorado						
2012-2004	22	19		22	19	
Corsica						
1996-1987	19 ^D	19 ^D		19 ^D	19 ^D	
Corvette						
2013-2005	21	21		21	21	
2004-1998	22	22		22	22	
1997-1995	20 ^N	20 ^N		20 ^N	20 ^N	
1994-1984	20 ^D	20 ^D		20 ^D	20 ^D	
1982-1968	16 ^D	16 ^D		16 ^D	16 ^D	
Cruze						
2013-2011	24	17		24	17	
El Camino						
1987-1978	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
Epica						
2006-2004	22	20		22	20	
Equinox						
2013-2010			13	24 ^F	17 ^F	13
2009-2005	24	19	15	24	19	15
Express 1500						
2013-1996	22	22		22	22	
Express 2500						
2013-1996	22	22		22	22	
Express 3500						
2013-1996	22	22		22	22	
Express 4500						
2013-2009	22	22		22	22	
Express Cargo						
2013	22	22		22	22	
Express Pasajeros						
2013	22	22		22	22	
G10						
1995-1990	18 ^D	18 ^D		18 ^D	18 ^D	
1989-1984	16 ^D	16 ^D		16 ^D	16 ^D	
1983-1975	16 ^E	16 ^E		16 ^E	16 ^E	
G10 Van						
1974-1970	16 ^E	16 ^E		16 ^E	16 ^E	
G20						
1995-1990	18 ^D	18 ^D		18 ^D	18 ^D	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Chevrolet						
G20						
1989-1984	16 ^D	16 ^D		16 ^D	16 ^D	
1983-1975	16 ^E	16 ^E		16 ^E	16 ^E	
G20 Van						
1974-1967	16 ^E	16 ^E		16 ^E	16 ^E	
G30						
2002-2001, 1996	22	22		22	22	
1995-1990	18 ^D	18 ^D		18 ^D	18 ^D	
1989-1984	16 ^D	16 ^D		16 ^D	16 ^D	
1983-1975	16 ^E	16 ^E		16 ^E	16 ^E	
G30 Van						
1974-1970	16 ^E	16 ^E		16 ^E	16 ^E	
HHR						
2011-2006	18	18		18	18	R11-A
Impala						
2014	24	19		24	19	
2013-2006				22	22	
2005-2000, 1996-1994	22 ^N	22 ^N		22 ^N	22 ^N	
1985-1971	18 ^D	18 ^D		18 ^D	18 ^D	
K10						
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1975	16 ^E	16 ^E		16 ^E	16 ^E	
K10 Pickup						
1974-1970	16 ^E	16 ^E		16 ^E	16 ^E	
K10 Suburban						
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1973	16 ^E	16 ^E		16 ^E	16 ^E	
K1500						
1999-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
K1500 Suburban						
1999-1995	18	18	14	18	18	14
1994-1992	18 ^D	18 ^D		18 ^D	18 ^D	
K20						
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1975	16 ^E	16 ^E		16 ^E	16 ^E	
K20 Pickup						
1974-1970	16 ^E	16 ^E		16 ^E	16 ^E	
K20 Suburban						
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1973	16 ^E	16 ^E		16 ^E	16 ^E	
K2500						
2000-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
K2500 Suburban						
1999-1995	18	18	14	18	18	14
1994-1992	18 ^D	18 ^D		18 ^D	18 ^D	
K30						
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1977	16 ^E	16 ^E		16 ^E	16 ^E	
K30 Pickup						
1974-1970	16 ^E	16 ^E		16 ^E	16 ^E	
K3500						
2000-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
K5 Blazer						
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Chevrolet						
K5 Blazer						
1980	16 ^E	16 ^E		16 ^E	16 ^E	
LUV						
1982-1981	18 ^E	18 ^E		18 ^E	18 ^E	
Lumina						
2001-1995	22	22		22	22	
1994-1990	20 ^N	20 ^N		20 ^N	20 ^N	
Lumina APV						
1996-1990	24 ^N	24 ^N	12 ^D	24 ^N	24 ^N	12 ^D
Malibu						
2013	24	19		24	19	
2012-2008				24 ^F	21 ^F	
2007-2004	22	20		22	20	
2003-1997	22	19		22	19	
1983-1978	18 ^D	18 ^D		18 ^D	18 ^D	
Metro						
2001-1998	20	19		20	19	
Monte Carlo						
2007-2006	22	22		22	22	
2005-1998	22	19		22	19	
1997-1995	22	22		22	22	
1988-1978	18 ^D	18 ^D		18 ^D	18 ^D	
Optra						
2009-2004	22	19	18	22	19	18
Orlando						
2012	24	19		24	19	
Prizm						
2002-1998	20	18		20	18	
R10						
1987	18	18		18	18	
R10 Suburban						
1988-1987	16 ^D	16 ^D		16 ^D	16 ^D	
1988-1987	18	18		18	18	
R1500 Suburban						
1991-1989	16 ^D	16 ^D		16 ^D	16 ^D	
R20						
1988-1987	18	18		18	18	
R20 Suburban						
1988-1987	16 ^D	16 ^D		16 ^D	16 ^D	
1988-1987	18	18		18	18	
R2500 Suburban						
1991-1990	16 ^D	16 ^D		16 ^D	16 ^D	
1991-1990	18	18		18	18	
1989	16 ^D	16 ^D		16 ^D	16 ^D	
R30						
1988-1987	18	18		18	18	
R3500						
1991-1989	18	18		18	18	
S10						
2004-1994	20	20		20	20	
1993-1982	16 ^D	16 ^D		16 ^D	16 ^D	
S10 Blazer						
1994-1983	16 ^D	16 ^D	12 ^D	16 ^D	16 ^D	12 ^D
Silverado						
1999	22	22		22	22	
Silverado 1500						
2013-2008				22 ^H	22 ^H	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Chevrolet						
Silverado 1500						
2007-1999	22	22		22	22	
Silverado 1500 HD						
2007-2005, 2003-2001	22	22		22	22	
Silverado 2500						
2013, 2009- 2007				22 ^H	22 ^H	
2006-1999	22	22		22	22	
Silverado 2500 HD						
2013-2008				22 ^H	22 ^H	
2007-2001	22	22		22	22	
Silverado 3500						
2013, 2009- 2008				22 ^H	22 ^H	
2007-2001	22	22		22	22	
Silverado 3500 HD						
2013-2007				22 ^H	22 ^H	
Sonic						
2013-2012				26 ^H	15 ^H	
Spark						
2013				24 ^F	16 ^F	R12-A
Spectrum						
1988-1985	17	17	15	17	17	15
Sprint						
1991-1989	19 ^D	18 ^D		19 ^D	18 ^D	
Suburban						
2013	22	22		22	22	R12-E
Suburban 1500						
2013-2011	22	22		22	22	R12-E
2010-2009	22 ^M	22 ^M		22 ^M	22 ^M	R12-E
2008-2007				22 ^H	22 ^H	R12-E
2006-2000	22	22	16	22	22	16
1999-1995	18	18	14 ^D	18	18	14 ^D
Suburban 2500						
2013-2011	22	22		22	22	R12-E
2010-2009	22 ^M	22 ^M		22 ^M	22 ^M	R12-E
2008-2007				22 ^H	22 ^H	R12-E
2006-2000	22	22	16	22	22	16
Tah						
2013-2011	22	22		22	22	R12-E
2010-2009	22 ^M	22 ^M		22 ^M	22 ^M	R12-E
2008-2007				22 ^H	22 ^H	R12-E
2006-2000	22	22	16	22	22	16
1999-1995	18	18	14 ^D	18	18	14 ^D
Tracker						
2004-1999	19	19	15	19	19	15
1998	17	17	15	17	17	15
Trailblazer						
2009-2007	22	22		22	22	R12-E
2006-2002	22	22	16	22	22	16
Traverse						
2013-2012			13 ^U	26 ^H	21 ^H	13 ^U
2011-2009				24 ^F	21 ^F	
Uplander						
2008-2005	24	22	16	24	22	16
V10						
1987	18	18		18	18	
V10 Suburban						
1988-1987	16 ^D	16 ^D		16 ^D	16 ^D	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Chevrolet						
V10 Suburban						
1988-1987	18	18		18	18	
V1500 Suburban						
1991-1989	16 ^D	16 ^D		16 ^D	16 ^D	
V20						
1987	18	18		18	18	
V20 Suburban						
1988-1987	16 ^D	16 ^D		16 ^D	16 ^D	
1988-1987	18	18		18	18	
V2500 Suburban						
1991-1989	16 ^D	16 ^D		16 ^D	16 ^D	
V30						
1988-1987	18	18		18	18	
V3500						
1991-1989	18	18		18	18	
Venture						
2005-1997	24	24	16	24	24	16
Volt						
2013-2011				26 ^F	26 ^F	
Chrysler						
200						
2013-2011				24	22	
300						
2013	24	21		24	21	
2012	24	22		24	22	
2011	24	21		24	21	
2010-2005	22	22		22	22	
300M						
2004-1999	24	22		24	22	
Aspen						
2009-2007	26	21		26	21	R14-C
Cirrus						
2000-1995	22	22		22	22	
Concorde						
2004-1997	24	22		24	22	
1996-1995	24	24		24	24	
1994-1993	24	22		24	22	
Cordoba						
1983-1979	18 ^D	18 ^D		18 ^D	18 ^D	
Crossfire						
2008-2004	20	22		20	22	
E Class						
1984-1983	16 ^D	16 ^D		16 ^D	16 ^D	
Fifth Avenue						
1989-1983	18 ^D	18 ^D		18 ^D	18 ^D	
Grand Voyager						
2002-2000	28	28	18	28	28	18
Imperial						
1993-1990, 1983-1981	18 ^D	18 ^D		18 ^D	18 ^D	
LHS						
2001-1999, 1997	24	22		24	22	
1996-1995	24	24		24	24	
1994	24	22		24	22	
Laser						
1986-1984	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D
LeBaron						
1995-1994	19 ^D	19 ^D		19 ^D	19 ^D	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Chrysler						
LeBaron						
1993-1987	18 ^D	18 ^D		18 ^D	18 ^D	
1986-1985	18 ^D	18 ^D	13 ^E	18 ^D	18 ^D	13 ^E
1984-1982	16 ^D	16 ^D	13 ^E	16 ^D	16 ^D	13 ^E
1981-1980	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
1979-1977	18 ^D	18 ^D		18 ^D	18 ^D	
New Yorker						
1996-1995	24	24		24	24	
1994	24	22		24	22	
1993-1989	18 ^D	18 ^D		18 ^D	18 ^D	
1988-1983	16 ^D	16 ^D		16 ^D	16 ^D	
PT Cruiser						
2010-2001	19	21	16	19	21	16
Pacifica						
2008-2004	22	22	14	22	22	14
Prowler						
2002-2001	17	19		17	19	
Sebring						
2010-2007	Sedan	24	22	24	22	
2010-1996	Convertible	22	22	22	22	
2006-2001	Sedan	22	22	22	22	
2005-2001	Coupe	24	21	24	21	
2000-1995	Coupe	24	22	24	22	
TC Maserati						
1991-1989	18	18		18	18	
Town & Country						
2013-2011	26	20	16	26	20	16
2010	26	20	16 ^B	26	20	16 ^B
2009-2008	26	20	16	26	20	16
2007-1996	28	28	16	28	28	16
1995	22	22	18	22	22	18
1994-1993	22	18	18	22	18	18
1992-1991	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D
1990	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
1988-1985	16 ^D	16 ^D		16 ^D	16 ^D	
Voyager						
2003-2000	28	28	18	28	28	18
Daewoo						
Lanos						
2002-1999	19	19	19	19	19	19
Leganza						
2002-1999	22	19		22	19	
Nubira						
2002-1999	20	20	15	20	20	15
Daihatsu						
Charade						
1992-1988	18 ^T	18 ^T	12	18 ^T	18 ^T	12
Rocky						
1992-1990	16 ^T	16 ^T	13	16 ^T	16 ^T	13
DeLorean						
DMC 12						
1983-1981	20	20		20	20	
Dodge						
400						
1983-1982	16 ^D	16 ^D		16 ^D	16 ^D	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Dodge						
600						
1988-1983	16 ^D	16 ^D		16 ^D	16 ^D	
Aries						
1989-1981	16 ^D	16 ^D	13 ^E	16 ^D	16 ^D	13 ^E
Aspen						
1980-1976	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
Avenger						
2013-2008				24	22	
2000-1995	24	22		24	22	
B100						
1980-1976	16 ^D	16 ^D		16 ^D	16 ^D	
B150						
1994-1981	16 ^D	16 ^D		16 ^D	16 ^D	
B1500						
1998-1996	18 ^D	18 ^D		18 ^D	18 ^D	
1995	16 ^D	16 ^D		16 ^D	16 ^D	
B200						
1980-1976	16 ^D	16 ^D		16 ^D	16 ^D	
B250						
1994-1981	16 ^D	16 ^D		16 ^D	16 ^D	
B2500						
1998-1996	18 ^D	18 ^D		18 ^D	18 ^D	
1995	16 ^D	16 ^D		16 ^D	16 ^D	
B300						
1980-1976	16 ^D	16 ^D		16 ^D	16 ^D	
B350						
1994-1981	16 ^D	16 ^D		16 ^D	16 ^D	
B3500						
1998-1996	18 ^D	18 ^D		18 ^D	18 ^D	
1995	16 ^D	16 ^D		16 ^D	16 ^D	
Caliber						
2012-2007	24	17		24	17	
Caravan						
2007-2001	28	28	16	28	28	16
2000-1996	28	28	18	28	28	18
1995	22	22	18	22	22	18
1994	22	18	18	22	18	18
1993-1991	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D
1990-1985	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
Challenger						
2013	22	22		22	22	
2012-2008	22	22		22	22	
Charger						
2013-2011	24	21		24	21	
2010-2006	22	22		22	22	
1987-1983	16 ^E	16 ^E	18 ^E	16 ^E	16 ^E	18 ^E
Colt						
1994-1993	20	18		20	18	
1992-1991	20	17		20	17	
1977-1971	16	16		16	16	
Conquest						
1986-1984	19 ^I	19 ^I	16 ^I	19 ^I	19 ^I	16 ^I
D100						
1989-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1987-1986, 1979-1975	18 ^E	18 ^E		18 ^E	18 ^E	
D150						
1993-1988	18 ^D	18 ^D		18 ^D	18 ^D	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Dodge						
D150						
1987-1977	18 ^E	18 ^E		18 ^E	18 ^E	
D200						
1980-1975	18 ^E	18 ^E		18 ^E	18 ^E	
D250						
1993-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1987-1981	18 ^E	18 ^E		18 ^E	18 ^E	
D300						
1980-1975	18 ^E	18 ^E		18 ^E	18 ^E	
D350						
1993-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1987-1981	18 ^E	18 ^E		18 ^E	18 ^E	
D50						
1982-1979	16 ^E	16 ^E		16 ^E	16 ^E	
Dakota						
2010-2005	21	21		21	21	
2004-1997	20	20		20	20	
1996-1987	18 ^D	18 ^D		18 ^D	18 ^D	
Dart						
2013	26	18		26	18	
Daytona						
1993-1984	18 ^D	18 ^D		18 ^D	18 ^D	
Diplomat						
1989-1977	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
Durango						
2013-2011	22	21		22	21	R12-A
2009-2004	26	21		26	21	R14-C
2003-1998	20	20	16	20	20	16
Dynasty						
1993-1988	18 ^D	18 ^D		18 ^D	18 ^D	
Grand Caravan						
2013	26	20		26	20	
2012-2008	26	20	16	26	20	16
2007-1996	28	28	16	28	28	16
1995	22	22	18	22	22	18
1994-1993	22	18	18	22	18	18
1992-1991	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D
1990-1988	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
Intrepid						
2004-1997	24	22		24	22	
1996-1995	24	24		24	24	
1994-1993	24	22		24	22	
Journey						
2013-2009	24	19		24	19	R12-A
Lancer						
1989-1985	18 ^D	18 ^D		18 ^D	18 ^D	
Magnum						
2008-2005	22	22	10	22	22	
Mini Ram						
1988-1984	18	18		18	18	
Mirada						
1983-1980	18 ^D	18 ^D		18 ^D	18 ^D	
Monaco						
1992-1990	20 ^D	20 ^D		20 ^D	20 ^D	
Neon						
2005-2000	22	19		22	19	
1999-1995	21	18		21	18	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS						
MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Dodge						
Nitro						
2012-2007	19	19		19	19	R11-A
Omni						
1990-1978	16 ^E	16 ^E	18 ^E	16 ^E	16 ^E	18 ^E
Power Ram 50						
1986-1983	18 ^E	18 ^E		18 ^E	18 ^E	
RD200						
1980-1978	18 ^E	18 ^E		18 ^E	18 ^E	
Raider						
1989-1987	16 ^E	16 ^E	15 ^I	16 ^E	16 ^E	15 ^I
Ram 1500						
2010	22	22		22	22	
2009-2002	24	24		24	24	
2001-1994	20	20		20	20	
Ram 1500 Van						
2003-1999	18	18		18	18	
1998-1996	18 ^D	18 ^D		18 ^D	18 ^D	
1995	16 ^D	16 ^D		16 ^D	16 ^D	
Ram 2500						
2010	22	22		22	22	
2009-2002	24	24		24	24	
2001-1994	20	20		20	20	
Ram 2500 Van						
2003-1999	18	18		18	18	
1998-1996	18 ^D	18 ^D		18 ^D	18 ^D	
Ram 3500						
2010	22	22		22	22	
2009-2002	24	24		24	24	
2001-1994	20	20		20	20	
Ram 3500 Van						
2003-1999	18	18		18	18	
1998-1996	18 ^D	18 ^D		18 ^D	18 ^D	
Ram 4000						
2008-2005, 2002	24	24		24	24	
2001-1995	20	20		20	20	
Ram 4500						
2010	22	22		22	22	
2009-2008	24	24		24	24	
Ram 50						
1993-1987	17 ^I	17 ^I		17 ^I	17 ^I	
1986-1983	16 ^E	16 ^E		16 ^E	16 ^E	
Ram 5500						
2010	22	22		22	22	
2009-2008	24	24		24	24	
Ramcharger						
1993-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1987-1974	18 ^E	18 ^E		18 ^E	18 ^E	
Rampage						
1984-1982	16 ^E	16 ^E		16 ^E	16 ^E	
Royal Mini Ram						
1987-1984	16 ^D	16 ^D		16 ^D	16 ^D	
Shadow						
1994-1987	18 ^D	18 ^D		18 ^D	18 ^D	
Spirit						
1995-1989	18 ^D	18 ^D		18 ^D	18 ^D	
Sprinter 2500						
2011-2008				26 ^H	24 ^H	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS						
MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Dodge						
Sprinter 2500						
2007-2003	24	22		24	22	
Sprinter 3500						
2011-2008				26 ^H	24 ^H	
2007-2003	24	22		24	22	
St. Regis						
1981-1979	18 ^D	18 ^D		18 ^D	18 ^D	
Stealth						
1996-1991	21	20		21	20	
Stratus						
2006, 2000-1995	22	22		22	22	
2005-2001 Coupe	24	21		24	21	
2005-2001 Sedan	22	22		22	22	
Viper						
2004-1992	16	16		16	16	
W100						
1989-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1987-1986, 1977-1975	18 ^E	18 ^E		18 ^E	18 ^E	
W150						
1993-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1987-1977	18 ^E	18 ^E		18 ^E	18 ^E	
W200						
1980-1975	18 ^E	18 ^E		18 ^E	18 ^E	
W250						
1993-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1987-1981	18 ^E	18 ^E		18 ^E	18 ^E	
W300						
1975	18 ^E	18 ^E		18 ^E	18 ^E	
W350						
1993-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1987-1981	18 ^E	18 ^E		18 ^E	18 ^E	
Eagle						
Medallion						
1989-1988	20	20	18 ^E	20	20	18 ^E
Premier						
1992-1988	20 ^D	20 ^D		20 ^D	20 ^D	
Summit						
1996-1993 Sedan	20	19		20	19	
1996-1992 Wagon	22	18	16	22	18	16
1992 Sedan	20	17		20	17	
1991	20	17		20	17	
1990-1989	19 ^I	17 ^I		19 ^I	17 ^I	
Talon						
1998-1995	24	22	19	24	22	19
1994-1992	20	20	18	20	20	18
1991-1990	19 ^I	19 ^I	19 ^I	19 ^I	19 ^I	19 ^I
Vision						
1997	24	22		24	22	
1996-1995	24	24		24	24	
1994-1993	24	22		24	22	
Fiat						
500						
2013-2011	24	14		24	14	R12-A
Ford						
Aerostar						
1997-1994	22	22	16 ^D	22	22	16 ^D



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Ford						
Aerostar						
1993-1986	22 ^N	22 ^N	16 ^D	22 ^N	22 ^N	16 ^D
Aspire						
1997-1994	20	16		20	16	
Bronco						
1996-1994	18	18		18	18	
1993-1980	18 ^D	18 ^D		18 ^D	18 ^D	
Bronco II						
1990-1984	18 ^D	18 ^D		18 ^D	18 ^D	
C-Max						
2013				28 ^H	26 ^H	R12-E
Club Wagon						
1997-1995	22	22		22	22	
Contour						
2000-1995	22	20		22	20	
Courier						
1982-1972	13 ^B	13 ^B				
Crown Victoria						
2011-1994	22	22		22	22	
1993-1992	22 ^N	22 ^N		22 ^N	22 ^N	
E-100 Econoline						
1983-1981	18 ^D	18 ^D		18 ^D	18 ^D	
1980-1970	19 ^D	19 ^D		19 ^D	19 ^D	
E-100 Econoline Club Wagon						
1983-1975	19 ^D	19 ^D		19 ^D	19 ^D	
E-150						
2013-2003	20	20		20	20	
E-150 Club Wagon						
2005-2003	20	20		20	20	
E-150 Econoline						
2002-1994	22	22		22	22	
1993-1992	22 ^N	22 ^N		22 ^N	22 ^N	
1991-1981	18 ^D	18 ^D		18 ^D	18 ^D	
1980-1975	19 ^D	19 ^D		19 ^D	19 ^D	
E-150 Econoline Club Wagon						
2002-1994	22	22		22	22	
1993-1992	22 ^N	22 ^N		22 ^N	22 ^N	
1991-1981	18 ^D	18 ^D		18 ^D	18 ^D	
1980-1975	19 ^D	19 ^D		19 ^D	19 ^D	
E-200 Econoline						
1974-1970	19 ^D	19 ^D		19 ^D	19 ^D	
E-250						
2013-2003	20	20		20	20	
E-250 Econoline						
2002-1994	22	22		22	22	
1993-1992	22 ^N	22 ^N		22 ^N	22 ^N	
1991-1981	18 ^D	18 ^D		18 ^D	18 ^D	
1980-1975	19 ^D	19 ^D		19 ^D	19 ^D	
E-250 Econoline Club Wagon						
1991-1981	18 ^D	18 ^D		18 ^D	18 ^D	
1980-1975	19 ^D	19 ^D		19 ^D	19 ^D	
E-250 Super Duty						
2005-2004	20	20		20	20	
E-300 Econoline						
1974-1970	19 ^D	19 ^D		19 ^D	19 ^D	
E-350						
2003	20	20		20	20	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Ford						
E-350 Club Wagon						
2005-2003	20	20		20	20	
E-350 Econoline						
2002-1994	22	22		22	22	
1993-1992	22 ^N	22 ^N		22 ^N	22 ^N	
1991-1981	18 ^D	18 ^D		18 ^D	18 ^D	
1980-1975	19 ^D	19 ^D		19 ^D	19 ^D	
E-350 Econoline Club Wagon						
2002-1994	22	22		22	22	
1993-1992	22 ^N	22 ^N		22 ^N	22 ^N	
1991-1981	18 ^D	18 ^D		18 ^D	18 ^D	
1980-1977	19 ^D	19 ^D		19 ^D	19 ^D	
E-350 Super Duty						
2013-2004	20	20		20	20	
E-450 Econoline Super Duty						
2002-2000	20	20		20	20	
E-450 Econoline Super Duty Stripped						
2002-2000	22	22		22	22	
E-450 Super Duty						
2013-2003	20	20		20	20	
E-450 Super Duty Stripped Chassis						
2003	20	20		20	20	
E-550 Econoline Super Duty						
2002	22	22		22	22	
E-550 Super Duty						
2003	20	20		20	20	
EXP						
1988-1982	18 ^D	18 ^D		18 ^D	18 ^D	
Econoline						
2002-1999	22	22		22	22	
Econoline Super Duty						
1999-1996	22	22		22	22	
Econoline Van						
2013	20	20		20	20	
Econoline Wagon						
2013	20	20		20	20	
Edge						
2013-2007	26	20		26	20	R14-D
Escape						
2012-2008				20 ^H	20 ^H	R12-E
2007-2004	20	18	10	20	18	
2003-2001	19	19		19	19	
Escort						
2003-2001	20	18		20	18	
2000-1994	20	18	13	20	18	13
1993-1991	20 ^N	18 ^D	14 ^D	20 ^N	18 ^D	14 ^D
1990-1981	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D
Excursion						
2005-2000	20	20	16	20	20	16
Expedition						
2013-2009	22	22		22	22	
2008	22	22	16	22	22	16
2007-1997	20	20	17	20	20	17
Explorer						
2010-2005	20	20	13	20	20	13
2004-2002	22	22	16	22	22	16
2001-1998	18	18	13	18	18	13



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Ford						
Explorer						
1997-1991	18	18	13 ^D	18	18	13 ^D
Explorer Sport Trac						
2010-2007	20	20		20	20	
2005-2001	18	18		18	18	
F-100						
1983-1980	18 ^D	18 ^D		18 ^D	18 ^D	
F-100 Ranger						
2001-1999	20	20		20	20	
1998-1997	22	22		22	22	
1996	18	18		18	18	
F-150						
2013				22	22	
2012-2009	22	22		22	22	
2008-1999	20	20		20	20	
1998-1997	22	22		22	22	
1996-1994	18	18		18	18	
1993-1980	18 ^D	18 ^D		18 ^D	18 ^D	
F-150 Heritage						
2004	20	20		20	20	
F-250						
2013				22	22	
2012-2009	22	22		22	22	
2008-1999	20	20		20	20	
1998-1997	22	22		22	22	
1996-1994	18	18		18	18	
1993-1980	18 ^D	18 ^D		18 ^D	18 ^D	
F-250 Super Duty						
2013				22	22	
2012-2009	22	22		22	22	
2008-1999	20	20		20	20	
F-350						
2013				22	22	
2012-2011, 2009	22	22		22	22	
2008-1999	20	20		20	20	
1998-1997	22	22		22	22	
1996-1994	18	18		18	18	
1993-1980	18 ^D	18 ^D		18 ^D	18 ^D	
F-350 Super Duty						
2013				22	22	
2012-2009	22	22		22	22	
2008-1999	20	20		20	20	
F-450						
2013				22	22	
2012-2011, 2009	22	22		22	22	
2008-1999	20	20		20	20	
1998-1997	22	22		22	22	
F-450 Super Duty						
2013				22	22	
2012-2009	22	22		22	22	
2008-1999	20	20		20	20	
F-550						
2013				22	22	
2012-2010	22	22		22	22	
F-550 Super Duty						
2013				22	22	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Ford						
F-550 Super Duty						
2012-2011	22	22		22	22	
2010-1999	20	20		20	20	
Fairmont						
1983-1978	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D
Festiva						
1993-1989	18	18	15	18	18	15
1988	17 ^I	17 ^I	15 ^E	17 ^I	17 ^I	15 ^E
Fiesta						
2013				26 ^F	16 ^F	R12-B
2012-2011				24 ^F	16 ^F	R12-B
Fiesta Ikon						
2013				26 ^F	16 ^F	R12-B
Five Hundred						
2007				24 ^F	20 ^F	
2006-2005				24 ^Q	20 ^Q	
Flex						
2014-2009	24	22		24	22	R12-B
Focus						
2013-2012				28 ^H	28 ^H	R12-B
2011-2000	22	19	15	22	19	15
Freestar						
2007-2004	24	20	16	24	20	16
Freestyle						
2007			13	24 ^F	20 ^F	13
2006-2005			13	24 ^Q	20 ^Q	13
Fusion						
2013				26 ^H	26 ^H	
2012-2006	24	19		24	19	
Granada						
1982-1975	16 ^D	16 ^D		16 ^D	16 ^D	
Grand Marquis						
2004-2003	22 ^N	22 ^N		22 ^N	22 ^N	
2002-2000	22	22		22	22	
LTD						
1986	18 ^D	18 ^D		18 ^D	18 ^D	
1985-1984	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
1983-1971	18 ^D	18 ^D		18 ^D	18 ^D	
LTD Crown Victoria						
1991-1987	18 ^D	18 ^D		18 ^D	18 ^D	
Mustang						
2014-2010				22 ^H	20 ^H	
2009-2005	22	20		22	20	
2004-1994	20	20		20	20	
1993-1983	16 ^D	16 ^D		16 ^D	16 ^D	
1982-1979	16 ^D	16 ^D	18 ^D	16 ^D	16 ^D	18 ^D
Probe						
1997	20	20	20	20	20	20
1996-1993	20	19	20	20	19	20
1992-1989			20			20
Ranger						
2012-1993	18	18		18	18	
1992-1983	18 ^D	18 ^D		18 ^D	18 ^D	
Taurus						
2013-2010				26 ^H	20 ^H	
2009-2008				24 ^F	20 ^F	
2007-1996	24	20	18	24	20	18



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Ford						
Taurus						
1995-1992	20	20	15 ^E	20	20	15 ^E
1991-1989	20 ^N	20 ^N	15 ^E	20 ^N	20 ^N	15 ^E
1988-1986	20 ^D	20 ^D	15 ^E	20 ^D	20 ^D	15 ^E
Taurus X						
2009-2008			15	24 ^H	20 ^H	15
Tempo						
1994-1986	20 ^D	20 ^D		20 ^D	20 ^D	
1985-1984	19 ^D	19 ^D		19 ^D	19 ^D	
Thunderbird						
2005-2002	24	22		24	22	
1997-1990	22 ^N	22 ^N		22 ^N	22 ^N	
1989	24 ^N	20 ^N		24 ^N	20 ^N	
1988-1983	18 ^D	18 ^D		18 ^D	18 ^D	
1982-1977	16 ^D	16 ^D		16 ^D	16 ^D	
Transit Connect						
2013-2010	26	18	14 ^C	26	18	14 ^C
Windstar						
2003-1995	24	20	16	24	20	16
GMC						
Acadia						
2013			10	24 ^H	21 ^H	
2012-2007			10	24 ^F	21 ^F	
C15						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	
C15 Suburban						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	
C15/C1500 Suburban						
1974-1973	16 ^E	16 ^E		16 ^E	16 ^E	
C1500						
1999-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1979	16 ^E	16 ^E		16 ^E	16 ^E	
C1500 Suburban						
1999-1995	18	18	13	18	18	13
1994-1992	18 ^D	18 ^D		18 ^D	18 ^D	
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1979	16 ^E	16 ^E		16 ^E	16 ^E	
C25						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	
C25 Suburban						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	
C25/C2500 Suburban						
1974-1973	16 ^E	16 ^E		16 ^E	16 ^E	
C2500						
2000-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1979	16 ^E	16 ^E		16 ^E	16 ^E	
C2500 Suburban						
1999-1995	18	18	13	18	18	13
1994-1992	18 ^D	18 ^D		18 ^D	18 ^D	
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1979	16 ^E	16 ^E		16 ^E	16 ^E	
C35						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
GMC						
C3500						
2002-2001	22	22		22	22	
2000-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1979	16 ^E	16 ^E		16 ^E	16 ^E	
Caballero						
1987-1978	18 ^D	18 ^D		18 ^D	18 ^D	
Canyon						
2012-2004	22	19		22	19	
Envoy						
2009-2007	22	22		22	22	R12-E
2006-2002	22	22	16	22	22	16
G15						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	
G1500						
1995-1991	18 ^D	18 ^D		18 ^D	18 ^D	
1990-1984	16 ^D	16 ^D		16 ^D	16 ^D	
1983-1979	16 ^E	16 ^E		16 ^E	16 ^E	
G25						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	
G2500						
1995-1992	18 ^D	18 ^D		18 ^D	18 ^D	
1991-1984	16 ^D	16 ^D		16 ^D	16 ^D	
1983-1979	16 ^E	16 ^E		16 ^E	16 ^E	
G35						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	
G3500						
1996	22	22		22	22	
1995-1993	18 ^D	18 ^D		18 ^D	18 ^D	
1992-1984	16 ^D	16 ^D		16 ^D	16 ^D	
1983-1979	16 ^E	16 ^E		16 ^E	16 ^E	
Jimmy						
2001-1995	20	20	14	20	20	14
1994-1992	18 ^D	18 ^D		18 ^D	18 ^D	
1991-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1973	16 ^E	16 ^E		16 ^E	16 ^E	
K15						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	
K15 Suburban						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	
K15/K1500 Suburban						
1974-1973	16 ^E	16 ^E		16 ^E	16 ^E	
K1500						
1999-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1979	16 ^E	16 ^E		16 ^E	16 ^E	
K1500 Suburban						
1999-1995	18	18	13	18	18	13
1994-1992	18 ^D	18 ^D		18 ^D	18 ^D	
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1979	16 ^E	16 ^E		16 ^E	16 ^E	
K25						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	
K25 Suburban						
1978-1975	16 ^E	16 ^E		16 ^E	16 ^E	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
GMC						
K25/K2500 Suburban						
1974-1973	16 ^E	16 ^E		16 ^E	16 ^E	
K2500						
2000-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1979	16 ^E	16 ^E		16 ^E	16 ^E	
K2500 Suburban						
1999-1995	18	18	13	18	18	13
1994-1992	18 ^D	18 ^D		18 ^D	18 ^D	
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1979	16 ^E	16 ^E		16 ^E	16 ^E	
K35						
1978-1977	16 ^E	16 ^E		16 ^E	16 ^E	
K3500						
2000-1995	18	18		18	18	
1994-1988	18 ^D	18 ^D		18 ^D	18 ^D	
1986-1985	16 ^D	16 ^D		16 ^D	16 ^D	
1984-1979	16 ^E	16 ^E		16 ^E	16 ^E	
P3500						
1999-1991	18	18		18	18	
1990-1985	16	16		16	16	
R1500						
1987	18	18		18	18	
R1500 Suburban						
1991-1987	16 ^D	16 ^D		16 ^D	16 ^D	
1991-1987	18	18		18	18	
R2500						
1989-1987	18	18		18	18	
R2500 Suburban						
1991-1987	16 ^D	16 ^D		16 ^D	16 ^D	
1991-1987	18	18		18	18	
R3500						
1991-1987	18	18		18	18	
S15						
1990-1982	16 ^D	16 ^D		16 ^D	16 ^D	
S15 Jimmy						
1991-1983	16 ^D	16 ^D		16 ^D	16 ^D	
Safari						
2005-1993	18 ^D	18 ^D	13 ^D	18 ^D	18 ^D	13 ^D
1992-1985	18 ^D	18 ^D		18 ^D	18 ^D	
Savana 1500						
2012-1996	22	22		22	22	
Savana 2500						
2012-1996	22	22		22	22	
Savana 3500						
2012-1996	22	22		22	22	
Savana 4500						
2012-2009	22	22		22	22	
Sierra						
2013, 2009-2007				22 ^H	22 ^H	
Sierra 1500						
2013-2008				22 ^H	22 ^H	
2007-1999	22	22		22	22	
Sierra 1500 HD						
2007-2005, 2003-2001	22	22		22	22	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
GMC						
Sierra 2500						
2004-1999	22	22		22	22	
Sierra 2500 HD						
2013-2008				22 ^H	22 ^H	
2007-2001	22	22		22	22	
Sierra 3500						
2007-2001	22	22		22	22	
Sierra 3500 HD						
2013-2007				22 ^H	22 ^H	
Sierra C3						
2001	22	22		22	22	
Sonoma						
2004-1994	20	20		20	20	
1993-1991	16 ^D	16 ^D		16 ^D	16 ^D	
Syclone						
1991	16 ^D	16 ^D		16 ^D	16 ^D	
Terrain						
2013-2010			12	24 ^F	17 ^F	12
Typhoon						
1993-1992	16 ^D	16 ^D	14 ^D	16 ^D	16 ^D	14
V1500						
1987	18	18		18	18	
V1500 Suburban						
1991-1987	16 ^D	16 ^D		16 ^D	16 ^D	
1991-1987	18	18		18	18	
V2500						
1987	18	18		18	18	
V2500 Suburban						
1991-1987	16 ^D	16 ^D		16 ^D	16 ^D	
1991-1987	18	18		18	18	
V3500						
1991-1987	18	18		18	18	
Yukon						
2013-2012	22	22		22	22	
2011-2007	22 ^M	22 ^M		22 ^M	22 ^M	R12-E
2006-2000	22	22	16	22	22	16
1999	18	18		18	18	
1998-1995	18	18	13 ^D	18	18	13 ^D
1994-1992	18 ^D	18 ^D	13 ^D	18 ^D	18 ^D	13 ^D
Yukon XL 1500						
2013-2012	22	22		22	22	
2011-2007	22 ^M	22 ^M		22 ^M	22 ^M	R12-E
2006-2000	22	22	16	22	22	16
Yukon XL 2500						
2013-2012	22	22		22	22	
2011	22 ^M	22 ^M		22 ^M	22 ^M	
2010-2007	22 ^M	22 ^M		22 ^M	22 ^M	R12-E
2006-2000	22	22	16	22	22	16
Geo						
Metro						
1997-1995	20	19		20	19	
1994-1993	20	18		20	18	
1992-1989	18	18	15	18	18	15
Prizm						
1997-1993	20	18		20	18	
Spectrum						
1989	18 ^E	18 ^E		18 ^E	18 ^E	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Geo						
Storm						
1993-1990	22	22	20	22	22	20
Tracker						
1997-1991	17	17	15	17	17	15
Honda						
Accord						
2013-2008			21			21
2007-2003	26	18		26	18	
2002-1998	24	19		24	19	
1997-1994	24	20	15	24	20	15
1993-1990	24	19	16 ^o	24	19	16 ^o
1989-1986	19	19	19	19	19	19
1981-1977			16 ^E			16 ^E
Accord Crosstour						
2011-2010			21			21
CR-V						
2013-2012			13			13
2011-2007						R14-B
2006-2002	21	20	13	21	20	13
2001-1997	20	19	13	20	19	13
CR-Z						
2013-2011	26	21		26	21	
CRX						
1991-1988	20	20		20	20	
Civic						
2013-2012	Coupe	28	24		28	24
2013-2012	Sedan	26	24		26	24
2011-2006	Coupe			28 ^F	24 ^F	
2011-2006	Sedan	26	22		26	22
2005-2004	DX	21	19		21	19
2005-2004	Si	24	16		24	16
2003-2001		21	19		21	19
2000-1996		20	18	15	20	18
1995-1992		22	18		22	18
1991-1988		20	19	16 ^E	20	19
1987-1986	CRX	20	20	18	20	20
1987	Base	20	19	16 ^E	20	19
1986	Base	18	18	16 ^E	18	18
1985-1984		18	18	16 ^E	18	18
1983-1980		17 ^E	17 ^E	13 ^E	17 ^E	17 ^E
Civic del Sol						
1997-1993		22	19		22	19
Crosstour						
2013-2012			21			21
Element						
2011-2003		20	20		20	R12-B
Fit						
2013-2009		28	14		28	14
2008-2007		24	16		24	16
Insight						
2013-2010		26	18	20	26	18
2006-2000		22	19	16	22	19
Odyssey						
2013-2005		26	22		26	22
2004-1999		24	21	17	24	21
1998		24	24	15	24	24



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Honda						
Odyssey						
1997-1995	24	24	15 ^e	24	24	15 ^e
Passport						
2002-1998	19	19	11	19	19	
1997-1994	18	18	15	18	18	15
Pilot						
2013	22	21	14	22	21	14
2012	22 ^u	21	14	22	21	14
2011-2009	22	21	14	22	21	14
2008	24	21	14	24	21	14
2007-2003	24	21	14	24	21	
Prelude						
2001-1997	21	19		21	19	
1996-1991	22	19		22	19	
1990-1988	20	19		20	19	
Ridgeline						
2013-2009	22	22		22	22	
2008-2006	24	22		24	22	
S2000						
2009-2000	16	20		16	20	
Hummer						
H1						
2006, 2004-2002	11 ^b	11 ^b				
H2						
2009-2003	17	17	10	17	17	
H3						
2010-2006	17	17	10	17	17	
H3T						
2010	17	17	10	17	17	
2009	17	16	11	17	16	
Hyundai						
Accent						
2013-2012	26	16		26	16	R11-A
2011-2006	22	16		22	16	R14-A
2005-1995	20	18	20	20	18	20
Azera						
2013-2012	26	18		26	18	
2011-2006	24	20		24	20	
Elantra						
2013-2011	28	14		28	14	
2010-2007	24	18		24	18	
2006-2001	20	18	20	20	18	20
2000-1996	20	18	14	20	18	14
1995-1992	20	19		20	19	
Entourage						
2010-2007	26	18		26	18	R16-A
Equus						
2013-2011	24	20		24	20	
Excel						
1994-1990	18	18	16	18	18	16
1989-1987	17	17		17	17	
1986	17 ¹	17 ¹		17 ¹	17 ¹	
Genesis						
2013-2012				24	20	
2011-2009				24 ^h	20 ^h	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Hyundai						
Genesis Coupe						
2013-2010	24	20		24	20	
Pony						
1987-1984	17 ^E	17 ^E	17 ^E	17 ^E	17 ^E	17 ^E
Santa Fe						
2013	26	14		26	14	R14-A
2012-2007	24	18		24	18	R14-A
2006-2001	22	20	13	22	20	13
Scoupe						
1995-1991	19	18		19	18	
Sonata						
2013-2011	26	18		26	18	
2010-2006	24	19		24	19	
2005-1999	22	20		22	20	
1998-1995	20	20		20	20	
1994-1989	20	18		20	18	
Stellar						
1987-1985	18 ^E	18 ^E		18 ^E	18 ^E	
Tiburon						
2008-2003, 2001-1997	22	18	20	22	18	20
Tucson						
2013	24	16		24	16	R12-A
2012-2010	24	16	12	24	16	12
2009-2005	24	16		24	16	
Veloster						
2013-2012	26	18		26	18	
Veracruz						
2012-2007				24 ^F	20 ^F	R14-A
XG300						
2001	22	20		22	20	
XG350						
2005-2002	22	20		22	20	
Infiniti						
EX35						
2012-2011				24 ^R	17 ^R	R14-B
2010-2008				22 ^R	18 ^R	R14-B
EX37						
2013				24 ^R	17 ^R	R14-B
FX35						
2012-2011				24 ^R	19 ^R	R14-B
2010-2009				22 ^R	19 ^R	R14-B
2008-2003	22	20		22	20	R14-B
FX37						
2013				24 ^R	19 ^R	R14-B
FX45						
2008-2003	22	20		22	20	R14-B
FX50						
2013-2011				24 ^R	19 ^R	R14-B
2010				22 ^V	19 ^V	
2009				22	19	
G20						
2002-1999, 1996-1991	21	19		21	19	
G35						
2007-2003 Coupe	24	17		24	17	
2006-2003 Sedan	22	18		22	18	
I30						
2001-2000	26	17		26	17	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Infiniti						
I30						
1999-1996	22	21		22	21	
I35						
2004-2002	26	17		26	17	
JX35						
2013						R12-E
M30						
1992-1990	21	19		21	19	
M35						
2010-2006	24	19		24	19	
M35h						
2013				26 ^v	19 ^v	
2012				26	19	
M37						
2013				26 ^v	19 ^v	
2012-2011				26	19	
M45						
2010-2006	24	19		24	19	
2004-2003	21	19		21	19	
M56						
2013				26 ^v	19 ^v	
2012-2011				26	19	
Q45						
2006-2002	26	18		26	18	
2001-1997	22	20		22	20	
1996-1990	21	21		21	21	
QX4						
2003-1997	22	21	10	22	21	
QX56						
2013-2011				24 ^v	19 ^v	R12-B
2010-2004	24	22		24	22	R12-B
Isuzu						
Amigo						
2000-1998	19	19		19	19	
1994-1989	18	18		18	18	
Ascender						
2008-2007	22	22		22	22	R12-E
2006-2003	22	22	16	22	22	16
Axiom						
2004-2002	20	19		20	19	R14-B
Hombre						
2000-1996	20	20		20	20	
I-Mark						
1989-1982	18 ^E	18 ^E	15 ^E	18 ^E	18 ^E	15 ^E
Impulse						
1992-1990	22	22	20	22	22	20
Oasis						
1999-1996	24	24	15 ^E	24	24	15 ^E
Pickup						
1995-1989	18	18		18	18	
1988-1981	17 ^E	17 ^E		17 ^E	17 ^E	
Rodeo						
2004-1998	19	19	13	19	19	13
1997-1991	18	18	13	18	18	13
Rodeo Sport						
2003-2001	19	19	13	19	19	13
Stylus						
1993-1991	22	20		22	20	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Isuzu						
Trooper						
2002-1992	20	20	15	20	20	15
1991-1989	17	17	16 ^E	17	17	16 ^E
1988-1984	17 ^E	17 ^E	16 ^E	17 ^E	17 ^E	16 ^E
VehiCROSS						
2001-1999	24	17		24	17	
i-280						
2006	22	19		22	19	
i-290						
2008-2007	22	19		22	19	
i-350						
2006	22	19		22	19	
i-370						
2008-2007	22	19		22	19	
Jaguar						
S-Type						
2008-2004	22	22		22	22	
2003-2002	24	19		24	19	
2001-2000	22	22		22	22	
Super V8						
2009				24 ^H	19 ^H	
2008-2005	24	19		24	19	
Vanden Plas						
2009-2004	24	19		24	19	
2003-1993	21 ^Y			21 ^Y		
X-Type						
2008-2002	22	19		22	19	
XF						
2013-2009				24 ^H	19 ^H	
XFR						
2012-2010	22	19		22	19	
XJ						
2013-2011				22 ^H	19 ^H	
1971-1970	14	14		14	14	
XJ12						
1996-1994	21 ^Y			21 ^Y		
XJ6						
1997-1993	21 ^Y			21 ^Y		
1992-1988	21 ^{PY}			21 ^{PY}		
1987-1982	15 ^P	15 ^P		15 ^P	15 ^P	
1981-1972	15 ^I	15 ^I		15 ^I	15 ^I	
XJ8						
2009-2004	21	21		21	21	
2003-1998	21 ^Y			21 ^Y		
XJR						
2009-2004	24	19		24	19	
2003-1995	21 ^Y			21 ^Y		
XJS						
1996-1995	15	15		15	15	
1994-1985	15 ^P	15 ^P		15 ^P	15 ^P	
1984-1976	15 ^I	15 ^I		15 ^I	15 ^I	
XK						
2013-2007				22	21	
XK8						
2006-1997	21	21		21	21	
XKR						
2012-2010	22	21		22	21	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Jaguar						
XKR						
2009-2000	21	21		21	21	
XKR-S						
2013-2012	22	21		22	21	
Jeep						
CJ5						
1983-1978	16 ^D	16 ^D		16 ^D	16 ^D	
CJ7						
1986-1978	11 ^D	11 ^D				
Cherokee						
2001-1997	18	18	13	18	18	13
1996-1984	18 ^D	18 ^D	11 ^D	18 ^D	18 ^D	
1983-1982	16 ^D	16 ^D	11 ^D	16 ^D	16 ^D	
1981-1978	16 ^D	16 ^D		16 ^D	16 ^D	
Comanche						
1992-1986	16 ^D	16 ^D		16 ^D	16 ^D	
Commander						
2010-2006	18	18		18	18	R14-C
Compass						
2014-2007	22	20	10	22	20	
Grand Cherokee						
2014	22	21		22	21	R12-A
2013	22	21		22	21	R12-A
2012-2011	22	21		22	21	R12-A
2010-2005	21	21		21	21	R14-C
2004-1999	21	21	10	21	21	
1998-1993	20	20	10	20	20	
Grand Wagoneer						
1993	20	20		20	20	
1991-1984	16 ^D	16 ^D		16 ^D	16 ^D	
J10						
1988-1978	16 ^D	16 ^D		16 ^D	16 ^D	
J20						
1988-1978	16 ^D	16 ^D		16 ^D	16 ^D	
Liberty						
2012-2002	19	19	10	19	19	
Patriot						
2014-2011	21	21	10	21	21	
2010-2007	22	20	10	22	20	
Scrambler						
1985-1981	16 ^D	16 ^D		16 ^D	16 ^D	
Wagoneer						
1990-1984	18 ^D	18 ^D		18 ^D	18 ^D	
1983-1978	16 ^D	16 ^D		16 ^D	16 ^D	
Wrangler						
2013-2007	15	15		15	15	R12-A
2006-2005	13	13	17	13	13	17
2004-1997	13	13	18	13	13	18
1995-1987	12 ^D	12 ^D	16 ^D	12 ^D	12 ^D	16 ^D
Kia						
Amanti						
2009-2004	24	18		24	18	
Borrego						
2011-2009	24	20		24	20	R14-A
Forte						
2014	28	14		28	14	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Kia						
Forte						
2013-2012	24	20		24	20	R12-A
2011	24	24		24	24	R12-A
2010	24	20		24	20	R12-A
Forte Koup						
2013-2010	24	20		24	20	R12-A
Forte5						
2013-2012	24	20		24	20	R12-A
Optima						
2013-2007	24	18		24	18	
2006-2001	22	20		22	20	
Rio						
2013-2012	26	16		26	16	R11-A
2011-2010	22	16		22	16	
2009-2006	22	16		22	16	R14-A
2005-2001	21	17		21	17	
Rio5						
2012	26	16		26	16	R11-A
Rondo						
2011-2007	26	16		26	16	R14-A
Sedona						
2012-2006	26	18		26	18	R16-A
2005-2002	24	24	18	24	24	18
Sephia						
2001-1994	21	19		21	19	
Sorento						
2014-2011	24	20		24	20	R11-A
2009-2003	24	18	14	24	18	14
Soul						
2013-2010	24	20		24	20	R11-A
Spectra						
2009-2004	24	16		24	16	R14-A
2003-2000	21	19	19	21	19	19
Spectra5						
2009-2005	24	16		24	16	R14-A
Sportage						
2013-2011	24	18		24	18	R12-A
2010-2005	24	16	12	24	16	12
2002-1995	20	20	16	20	20	16
Land Rover						
Defender 90						
1997, 1995-1994	13	13	11	13	13	
Discovery						
2004-2000	LR-21 ^x	LR-21 ^x				R14-D
1999-1994	18	18	14	18	18	14
Freelander						
2005-2002	22	21		22	21	
LR2						
2013-2008				24 ^{''}	20 ^{''}	14
LR3						
2009-2007			16	22	22	16
2006	22	22	16	22	22	16
2005			16	22	22	16
LR4						
2013			16	22	22	16
2012-2011	22	22	16	22	22	16



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Land Rover						
LR4						
2010			16	22	22	16
Range Rover						
2013	LR-26 ^x	LR-26 ^x	17			17
2012-2002	LR-26 ^x	LR-26 ^x	18			18
2001-1996	22	22	19	22	22	19
1995	18 ^{AP}	18 ^{AP}	18	18 ^{AP}	18 ^{AP}	18
1995	22 ^B	22 ^B		22 ^B	22 ^B	
1994-1990	18 ^P	18 ^P		18 ^P	18 ^P	
1989-1987	17 ^I	17 ^I		17 ^I	17 ^I	
Range Rover Evoque						
2013-2012	LR-26 ^x	LR-26 ^x				
Range Rover Sport						
2013-2006			16	22	22	16
Lexus						
CT200h						
2013-2011	26	18		26	18	
ES300						
2003-1997	22	18		22	18	
1996-1992	21	19		21	19	
ES300h						
2013	24	18		24	18	
ES330						
2006-2004	24	20		24	20	
ES350						
2013-2007	24	18		24	18	
GS300						
2006	24	19		24	19	
2005-1998	24	20		24	20	
1997-1993	21	19		21	19	
GS350						
2013	26	18		26	18	
2011-2007	24	19		24	19	
GS400						
2000-1998	24	20		24	20	
GS430						
2007-2006	24	19		24	19	
2005-2001	24	20		24	20	
GS450h						
2013	26	18		26	18	
2011-2007	24	19		24	19	
GS460						
2011-2008	24	19		24	19	
GX460						
2013	26	20		26	26	R12-A
2012-2010	26	20		26	20	R12-A
GX470						
2009-2003	22	21		22	21	R14-A
HS250h						
2012-2010	26	18		26	18	
IS F						
2013-2008	22	20		22	20	
IS250						
2013-2006	22	20		22	20	
IS300						
2005-2001	22	20		22	20	
IS350						
2013-2006	22	20		22	20	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Lexus						
LS400						
2000-1990	22	16		22	16	
LS430						
2006-2001	24	16		24	16	
LS460						
2013-2007	24	17		24	17	
LS600h						
2013-2008	24	17		24	17	
LX450						
1997-1996	18	16		18	16	
LX470						
2007-2000	24	22		24	22	
LX570						
2013, 2011-2008	24	22		24	22	R12-A
RX300						
2003-1999	24	21	16	24	21	16
RX330						
2006-2004	26	22		26	22	R14-A
RX350						
2013-2010	26	22	16	26	22	16
2009-2007	26	22		26	22	R14-A
RX400h						
2008-2006	26	22		26	22	R14-A
RX450h						
2013-2010	26	22	16	26	22	16
SC300						
2000-1992	21	20		21	20	
SC400						
2000-1992	21	20		21	20	
SC430						
2010-2002	24	20		24	20	
Lincoln						
Aviator						
2005-2003	22	22	16	22	22	16
Blackwood						
2003-2002	22	22		22	22	
Continental						
2002-1998	24	20		24	20	
1997-1992	20	20		20	20	
1991-1988	20 ^N	20 ^N		20 ^N	20 ^N	
1980-1970	18 ^D	18 ^D		18 ^D	18 ^D	
LS						
2006-2000	24	19		24	19	
MKS						
2012-2009				26 ^H	20 ^H	
MKT						
2013-2010				24 ^H	22 ^H	R12-E
MKX						
2013-2007	26	20		26	20	R14-D
MKZ						
2013				22 ^H	20 ^H	
2012-2007	24	19		24	19	
Mark IV						
1976-1972	18 ^D	18 ^D		18 ^D	18 ^D	
Mark LT						
2008-2006	20	20		20	20	
Mark V						
1979-1977	18 ^D	18 ^D		18 ^D	18 ^D	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Lincoln						
Mark VI						
1983-1980	18 ^D	18 ^D		18 ^D	18 ^D	
Mark VII						
1992-1984	18 ^D	18 ^D		18 ^D	18 ^D	
Mark VIII						
1998-1993	22	22		22	22	
Navigator						
2013-2009	22	22		22	22	
2008	22	22	16	22	22	16
2007-2003	20	20	17	20	20	17
2002-1998	20	20	16	20	20	16
Town Car						
2011-1993	22	22		22	22	
1992-1990	22 ^N	22 ^N		22 ^N	22 ^N	
1989-1981	18 ^D	18 ^D		18 ^D	18 ^D	
Zephyr						
2006	24	19		24	19	
Lotus						
Elan						
1973-1970	14	14		14	14	
Elise						
2010-2009	Front	26	26	26	26	26
2008-2004		26 ^Y		26 ^Y		
Esprit						
2000		24 ^Y		24 ^Y		
Europa						
1975-1970		16		16		
Evora						
2012-2010		26		26		
Exige						
2010-2009	Front	26	26	26	26	26
2008-2005		26 ^Y		26 ^Y		
Maserati						
228i						
1990-1989		20	20	20	20	
425						
1987-1986		20	20	20	20	
430i						
1990-1989		20	20	20	20	
Biturbo						
1986-1984		20	20	20	20	
Bora						
1979-1971		18	18	18	18	
Coupe						
2007-2003		22	22	22	22	
GranSport						
2007-2005		22	22	22	22	
GranTurismo						
2009-2008		26	17	26	17	
Khamsin						
1979-1974		18	18	18	18	
Merak						
1979-1972		18	18	18	18	
Quattroporte						
2009-2004		26	18	26	18	
Spyder						
2006-2002		22	22	22	22	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Maserati						
Spyder						
1991-1989, 1987-1986	20	20		20	20	
Mazda						
2						
2013-2011	24	14		24	14	R14-B
3						
2013-2010	24	19		24	19	R14-A
2009-2004	22	18		22	18	R14-D
3 Sport						
2013-2012	24	19		24	19	R14-A
323						
1995-1990	21	18		21	18	
1989-1986	18	18	18	18	18	18
5						
2012	26	16		26	16	R12-A
2010-2006	26	16		26	16	R14-A
6						
2014-2009	24	18		24	18	
2008-2003	22	18		22	18	
626						
2002-1998	20	19		20	19	
1997-1993	21	20		21	20	
1992-1988	19	19	22	19	19	22
1987-1986	18	18		18	18	
1985-1979	17 ¹	17 ¹		17 ¹	17 ¹	
929						
1995-1992	21	20		21	20	
1991-1988	20	19		20	19	
B1600						
1976-1975	13 ^E	13 ^E		13 ^E	13 ^E	
B1800						
1978-1977	13 ^E	13 ^E		13 ^E	13 ^E	
B2000						
1987	18	18		18	18	
1986	17 ¹	17 ¹		17 ¹	17 ¹	
1984-1979	13 ^E	13 ^E		13 ^E	13 ^E	
B2200						
1993-1987	18	18		18	18	
1984-1982	13 ^E	13 ^E		13 ^E	13 ^E	
B2300						
2009-2001, 1997-1994	18	18		18	18	
B2500						
2001-1998	18	18		18	18	
B2600						
1993-1987	18	18		18	18	
B3000						
2007-1994	18	18		18	18	
B4000						
2009-1994	18	18		18	18	
CX-5						
2014-2013	24	18		24	18	R14-A
CX-7						
2012-2007	26	16		26	16	R14-A
CX-9						
2013-2007	26	16		26	16	R14-A
GLC						
1985-1984	17 ¹	17 ¹	15 ^E	17 ¹	17 ¹	15 ^E



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group		STANDARD BLADES			BEAM BLADES		
		Driver	Passenger	Rear	Driver	Passenger	Rear
Mazda							
GLC							
1983-1981	Hatchback	17 ¹	17 ¹	15 ^E	17 ¹	17 ¹	15 ^E
1983-1981	Wagon	15 ^E	15 ^E	13	15 ^E	15 ^E	13
1980-1977		15	15	14	15	15	14
MPV							
2006-2000		24	24	16	24	24	16
1998-1989		22	20	16	22	20	16
MX-3							
1996-1992		21	18	21	21	18	21
MX-5 Miata							
2013-2006		18	18		18	18	
MX-6							
1997-1993		20	20		20	20	
1992-1988		19	19		19	19	
Miata							
2005-1999, 1997-1990		18	18		18	18	
Millenia							
2002-1995		21	20		21	20	
Navajo							
1994-1991		18	18		18	18	
Protege							
2003-2000		21	19		21	19	
1999-1990		21	18		21	18	
Protege5							
2003-2002		21	19		21	19	
RX-7							
1995-1993		20	20	18	20	20	18
1991-1986		20	20	22	20	20	22
1985-1979		17 ¹	17 ¹	17 ¹	17 ¹	17 ¹	17 ¹
RX-8							
2011-2004		20	18		20	18	
Rotary Pickup							
1977-1975		13 ^E	13 ^E		13 ^E	13 ^E	
Tribute							
2011-2008					20 ^H	20 ^H	R12-E
2006-2001		20	18	10	20	18	
Mercedes-Benz							
190D							
1989-1984		24 ^V			24 ^V		
190E							
1993-1986		24 ^V			24 ^V		
1985-1984		20	20		20	20	
240D							
1983-1977		20	20		20	20	
260E							
1989-1987		24 ^V			24 ^V		
280S							
1976-1975		19	18		19	18	
280SE							
1980-1977		19	18		19	18	
300CD							
1985-1978		20	20	16	20	20	16
300CE							
1993-1988		24 ^V		18	24 ^V		18
300D							
1993-1990, 1987		24 ^V			24 ^V		



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Mercedes-Benz						
300D						
1985-1977	20	20		20	20	
300E						
1993-1986	24 ^Y			24 ^Y		
300SDL						
1987-1986	21	21		21	21	
300SEL						
1973-1970	16	16		16	16	
300SL						
1993-1990	24 ^Y			24 ^Y		
300TD						
1987	24 ^Y			24 ^Y		
1985-1979	20	20	16	20	20	16
300TE						
1993-1988	24 ^Y		18	24 ^Y		18
350SDL						
1991-1990	21	21		21	21	
380SL						
1985-1981	19	19		19	19	
380SLC						
1981	19	19		19	19	
400E						
1993-1992	24 ^Y			24 ^Y		
500E						
1993-1992	24 ^Y			24 ^Y		
500SL						
1993-1990	24 ^Y			24 ^Y		
560SL						
1989-1986	18	18		18	18	
600SL						
1993	24 ^Y			24 ^Y		
C180						
2013				24 ^O	24 ^O	
C200						
2013				24 ^O	24 ^O	
2004				22 ^J	22 ^J	
2003-2001	24	22		24	22	
C220						
1997-1994	24 ^Y			24 ^Y		
C230						
2013, 2009				24 ^O	24 ^O	
2008-2004				22 ^J	22 ^J	
2003-2002	24	22	16	24	22	16
2000-1996	24 ^Y			24 ^Y		
C240						
2005-2004				22 ^J	22 ^J	
2003-2001	24	22	16	24	22	16
C250						
2013-2010				24 ^O	24 ^O	
C280						
2009-2006				22 ^J	22 ^J	
2000-1994	24 ^Y			24 ^Y		
C300						
2013-2009				24 ^O	24 ^O	
2008				22 ^J	22 ^J	
C32 AMG						
2004				22 ^J	22 ^J	
2003-2002	24	22		24	22	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Mercedes-Benz						
C320						
2005-2004				22 'J	22 'J	
2003-2001	24	22		24	22	
C350						
2013-2010				24 'Q	24 'Q	
2009				24 'Q	24 'Q	
2008-2006				22 'J	22 'J	
C36 AMG						
1997-1995	24 'Y			24 'Y		
C43 AMG						
2000-1998	24 'Y			24 'Y		
C55 AMG						
2007-2005				22 'J	22 'J	
C63 AMG						
2013-2009				24 'Q	24 'Q	
2008				22 'J	22 'J	
CL 63AMG						
2013				26 'Q	26 'Q	
CL200						
2003-2002				26 'Q	26 'Q	
CL230						
2005-2002				26 'Q	26 'Q	
CL500						
2013, 2009-2000				26 'Q	26 'Q	
CL55 AMG						
2006-2001				26 'Q	26 'Q	
CL550						
2013-2007				26 'Q	26 'Q	
CL600						
2013-2001				26 'Q	26 'Q	
1999-1997	24 'Y			24 'Y		
CL63 AMG						
2013-2008				26 'Q	26 'Q	
CL65 AMG						
2013-2008, 2006-2005				26 'Q	26 'Q	
CLK280						
2009-2007				22 'J	22 'J	
CLK320						
2005-2004				22 'J	22 'J	
2003-1997	24 'Y			24 'Y		
CLK430						
2003-1999	24 'Y			24 'Y		
CLK500						
2006-2003	24 'Y			24 'Y		
CLK55 AMG						
2006-2001	24 'Y			24 'Y		
CLK550						
2009-2007				22 'J	22 'J	
CLK63 AMG						
2009-2007				22 'J	22 'J	
CLS350						
2013				24 'Q	24 'Q	
CLS500						
2013				24 'Q	24 'Q	
2006				26 'Q	26 'Q	
CLS55 AMG						
2006				26 'Q	26 'Q	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Mercedes-Benz						
CLS550						
2013-2011				24 °	24 °	
2010-2007				26 °	26 °	
CLS63 AMG						
2013-2011				24 °	24 °	
2010-2007				26 °	26 °	
E200						
2013				26 °	26 °	R12-B
E250						
2013				26 °	26 °	
E280						
2009-2007				26 °	26 °	
E300						
2013-2012, 2010-2008 1999-1995	24 °		16	24 °	26 °	R12-B 16
E320						
2009-2008				26 °	26 °	
2007-2003			17	26 °	26 °	17
2002-1994	24 °		16	24 °		16
E350						
2013-2011				26 °	26 °	R12-B
2010				24 °	24 °	R12-B
2009-2006				26 °	26 °	
E420						
1999-1997, 1995-1994	24 °		18	24 °		18
E430						
2002-1998	24 °		16	24 °		16
E500						
2013, 2009- 2007				26 °	26 °	
2006-2003			17	26 °	26 °	17
2002, 1997, 1994	24 °		18	24 °		18
E55 AMG						
2013				26 °	26 °	R12-B
2006-2003			17	26 °	26 °	17
2002-1998	24 °		16	24 °		16
E550						
2013-2011				26 °	26 °	R12-B
2010				24 °	24 °	R12-B
2009-2007			17	26 °	26 °	17
E63 AMG						
2013-2011				26 °	26 °	R12-B
2010				24 °	24 °	R12-B
2009-2007			17	26 °	26 °	17
G500						
2009-2002	16	16	15	16	16	15
G55 AMG						
2011-2003	16	16	15	16	16	15
G550						
2011	16	16		16	16	
2010-2009	16	16	15	16	16	15
GL320						
2009-2007				26 °	21 °	R14-D
GL350						
2013				26 °	22 °	
2012-2010				26 °	21 °	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Mercedes-Benz						
GL450						
2013				26 ^F	22 ^F	
2012-2007				26 ^H	21 ^H	
GL500						
2009-2008				26 ^H	21 ^H	
GL500 AMG						
2013				26 ^F	22 ^F	
GL550						
2013				26 ^F	22 ^F	
2012-2008				26 ^H	21 ^H	
GL63 AMG						
2013				26 ^F	22 ^F	
GLK250						
2013				22 ^Q	19 ^Q	
GLK280						
2009				21 ^Q	19 ^Q	R14-D
GLK350						
2013-2012				22 ^Q	19 ^Q	R14-D
2011-2009				21 ^Q	19 ^Q	R14-D
ML320						
2009-2007				26 ^H	21 ^H	
2003-1998	22	22	16	22	22	16
ML350						
2013				26 ^F	22 ^F	
2012				28 ^{AH}	21 ^{AH}	
2012				26 ^{BF}	22 ^{BF}	
2011-2005				26 ^H	21 ^H	
2004-2003	22	22		22	22	
ML430						
2001-1998	22	22	16	22	22	16
ML450						
2011-2010				26 ^H	21 ^H	
ML500						
2013				26 ^F	22 ^F	
2009-2006				26 ^H	21 ^H	
2005			16	26 ^H	21 ^H	16
2004-2002	22	22	16	22	22	16
ML55 AMG						
2003-2000	22	22	16	22	22	16
ML550						
2013				26 ^F	22 ^F	
2012				28 ^{AH}	21 ^{AH}	
2012				26 ^{BF}	22 ^{BF}	
2011-2008				26 ^H	21 ^H	
ML63 AMG						
2013				26 ^F	22 ^F	
2012				28 ^{AH}	21 ^{AH}	
2012				26 ^{BF}	22 ^{BF}	
2011-2007				26 ^H	21 ^H	
R320						
2009-2007				26 ^H	21 ^H	
R350						
2012-2006				26 ^H	21 ^H	
R500						
2008-2006				26 ^H	21 ^H	
R63 AMG						
2007				26 ^H	21 ^H	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Mercedes-Benz						
S350						
2013-2012, 2006				26 °	26 °	
1995-1994	24 Y			24 Y		
S400						
2013-2010				26 °	26 °	
S430						
2006-2001				28 °	28 °	
2000	28	28		28	28	
S450						
2011-2008				26 °	26 °	
S500						
2011-2000				26 °	26 °	
1999-1994	24 Y			24 Y		
S55 AMG						
2006-2002				26 °	26 °	
2001	26 °	26 °		26 °	26 °	
S550						
2013-2007				26 °	26 °	
S600						
2013-2001				26 °	26 °	
1998-1994	24 Y			24 Y		
S63 AMG						
2013-2008				26 °	26 °	
S65 AMG						
2013-2005				26 °	26 °	
SL320						
1997-1994	24 Y			24		
SL500						
2009-2002				26 °	26 °	
2001-1994	24			24		
SL55 AMG						
2008-2002				26 °	26 °	
SL550						
2013				26 F	22 F	
2012-2011, 2009-2007				26 °	26 °	
SL60 AMG						
1999-1997	24 Y			24 Y		
SL600						
2009-2002				26 °	26 °	
2001-1994	24 Y			24 Y		
SL63 AMG						
2013				26 F	22 F	
2012-2011, 2009				26 °	26 °	
SL65 AMG						
2013				26 F	22 F	
2011, 2009- 2005				26 °	26 °	
SLK200						
2009-2005				26 "	26 "	
2004-2003	Front	22	22	22	22	22
SLK230						
2004-1998	Front	22	22	22	22	22
2002-1998		22		22		
SLK250						
2013				22 "	22 "	
SLK280						
2008-2006				26 "	26 "	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group		STANDARD BLADES			BEAM BLADES		
		Driver	Passenger	Rear	Driver	Passenger	Rear
Mercedes-Benz							
SLK300							
2011					26 ^Q	26 ^Q	
2010-2009					26 ^H	26 ^H	
SLK32 AMG							
2004-2003					26 ^H	26 ^H	
2004-2002	Front	22	22	22	22	22	22
2002		22			22		
SLK320							
2004-2001	Front	22	22	22	22	22	22
SLK350							
2013-2012					22 ^H	22 ^H	
2011					26 ^Q	26 ^Q	
2010					26 ^H	26 ^H	
2009-2005					22 ^H	22 ^H	
SLK55 AMG							
2013					22 ^H	22 ^H	
2010-2005					26 ^H	26 ^H	
SLR McLaren							
2009-2005					26 ^Q	26 ^Q	
Sprinter 2500							
2013-2010					26 ^H	24 ^H	
Sprinter 3500							
2013-2010					26 ^H	24 ^H	
Mercury							
Capri							
1994-1991		20	18		20	18	
1986-1983		16 ^D	16 ^D		16 ^D	16 ^D	
1982-1981		16 ^D	16 ^D	18 ^D	16 ^D	16 ^D	18 ^D
1980-1979		17 ^D	17 ^D	18 ^D	17 ^D	17 ^D	18 ^D
Cougar							
2002-1999		22	19		22	19	
1997-1990		22 ^N	22 ^N		22 ^N	22 ^N	
1989		24 ^N	20 ^N		24 ^N	20 ^N	
1988-1983		18 ^D	18 ^D		18 ^D	18 ^D	
1982-1974		16 ^D	16 ^D		16 ^D	16 ^D	
Grand Marquis							
2011-1994		22	22		22	22	
1993-1992		22 ^N	22 ^N		22 ^N	22 ^N	
1991-1975		18 ^D	18 ^D		18 ^D	18 ^D	
LN7							
1983-1982		18 ^D	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D
Lynx							
1987-1981	Hatchback	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D
1987-1981	Wagon	18 ^D	18 ^D	15 ^E	18 ^D	18 ^D	15 ^E
Marauder							
2004-2003		22	22		22	22	
Mariner							
2011					20 ^H	20 ^H	
2010-2008					20 ^H	20 ^H	R12-E
2007-2005		20	18	10	20	18	
Marquis							
1986-1971		18 ^D	18 ^D		18 ^D	18 ^D	
Milan							
2011-2006		24	19		24	19	
Monarch							
1980-1975		16 ^D	16 ^D		16 ^D	16 ^D	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Mercury						
Montego						
2007				24 ^F	20 ^F	
2006-2005				24 ^Q	20 ^Q	
Monterey						
2007-2004	24	20	16	24	20	16
Mountaineer						
2010-2005	20	20	13	20	20	13
2004-2002	22	22	16	22	22	16
2001-1997	18	18	14 ^D	18	18	14 ^D
Mystique						
2000-1995	22	20		22	20	
Sable						
2009-2008				24 ^F	20 ^F	
2005-1996	24	20	18	24	20	18
1995-1992	20	20	15	20	20	15
1991-1989	20 ^N	20 ^N	15 ^E	20 ^N	20 ^N	15 ^E
1988-1986	20 ^D	20 ^D	15 ^E	20 ^D	20 ^D	15 ^E
Topaz						
1994-1986	20 ^D	20 ^D		20 ^D	20 ^D	
1985-1984	19 ^D	19 ^D		19 ^D	19 ^D	
Tracer						
1999-1994	20	18	13	20	18	13
1993-1991	20 ^N	18 ^D	13	20 ^N	18 ^D	13
1989-1987	18 ^D	18 ^D	13 ^E	18 ^D	18 ^D	13 ^E
Villager						
2002-1999	22	22	14	22	22	14
1998-1993	22	22	13 ^D	22	22	13 ^D
Zephyr						
1983-1978	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D
Merkur						
Scorpio						
1989-1988	20 ^P	20 ^P		20 ^P	20 ^P	
XR4Ti						
1989-1985	20 ^P	20 ^P		20 ^P	20 ^P	
Mini						
Cooper						
2013-2012	Coupe			20 ^H	21 ^H	
2012	Convertible	18	19	18	19	
2011-2002		18	19	18	19	
Cooper Countryman						
2012-2011				19 ^H	20 ^H	
Mitsubishi						
3000GT						
1999-1991	21	20	20 ^E	21	20	20 ^E
Cordia						
1988-1983	19 ^I	19 ^I	17 ^I	19 ^I	19 ^I	17 ^I
Diamante						
2004-1997	22	20		22	20	
1996-1992	20	19	16	20	19	16
Eclipse						
2012-2006	24	22	17	24	22	17
2005-2000	24	21	22	24	21	22
1999-1995	24	22	18	24	22	18
1994-1992	20	20	18	20	20	18
Endeavor						
2011-2010, 2008-2004	26	21		26	21	R14-A



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Mitsubishi						
Expo						
1995-1992	19	19		19	19	
Expo LRV						
1994-1992	19	18	16	19	18	16
1994-1992	22	19		22	19	
Galant						
2012-2004	26	19		26	19	
2003-1999	24	18		24	18	
1998-1994	21	19		21	19	
1993-1990	19	18		19	18	
Lancer						
2013-2008	26	18	14	26	18	14
2007-2002	24	18		24	18	
Mighty Max						
1996-1995	19	19		19	19	
1994-1989	17 ¹	17 ¹		17 ¹	17 ¹	
1994-1989	19	19		19	19	
1988-1987	17 ¹	17 ¹		17 ¹	17 ¹	
1986-1983	16 ^E	16 ^E		16 ^E	16 ^E	
Mirage						
2002-1997	21	19		21	19	
1996-1993	20	19		20	19	
1992-1991	20	17		20	17	
Montero						
2006-2001	20	20	16	20	20	16
2000-1997	19	19	15	19	19	15
1996-1989	19	19		19	19	
1988-1985	16	16		16	16	
Montero Sport						
2004-1997	20	20	17	20	20	17
Outlander						
2013-2007	24	21		24	21	R12-B
2006-2003	22	19		22	19	R14-A
Outlander Sport						
2013-2011	24	21		24	21	
Precis						
1994-1993	19	19		19	19	
1992-1988	18	18	16	18	18	16
1987	17 ¹	17 ¹	17 ¹	17 ¹	17 ¹	17 ¹
Raider						
2009-2006	21	21		21	21	
Sigma						
1990-1989	17 ^K	17 ^K		17 ^K	17 ^K	
1990-1989	19	19		19	19	
Starion						
1989-1983	19 ¹	19 ¹	17 ¹	19 ¹	19 ¹	17 ¹
Tredia						
1988	16	16		16	16	
1987-1983	17 ¹	17 ¹		17 ¹	17 ¹	
Van						
1990-1987	17 ¹	17 ¹	15 ^E	17 ¹	17 ¹	15 ^E
i-MiEV						
2013-2012	24	20		24	20	R12-B
Mitsubishi Fuso						
FE						
1995-1989	19	19		19	19	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Mitsubishi Fuso						
FG						
1993-1990	19	19		19	19	
FH						
1995-1989	19	19		19	19	
FK						
1995-1989	19	19		19	19	
FM						
1995-1989	19	19		19	19	
Nissan						
200SX						
1998-1995	21	19		21	19	
1988-1987	21	21	19	21	21	19
1986-1984	19	19	17	19	19	17
1983-1980	19 ¹	19 ¹	18 ^E	19 ¹	19 ¹	18 ^E
240SX						
1998-1995	21	20		21	20	
1994-1989	20	20		20	20	
280Z						
1978-1975	17 ¹	17 ¹	17 ¹	17 ¹	17 ¹	17 ¹
280ZX						
1983-1979	17 ¹	17 ¹	17 ¹	17 ¹	17 ¹	17 ¹
300ZX						
1996	21	21	16	21	21	16
1995-1990	21	21	19	21	21	19
1989-1987	19	19	19	19	19	19
1986	19	19	17	19	19	17
310						
1982-1979	17 ^E	17 ^E		17 ^E	17 ^E	
350Z						
2009-2003	20	18	18	20	18	18
370Z						
2013				21 ^K	19 ^K	
2012-2009	21	19		21	19	
510						
1981-1978	17 ¹	17 ¹		17 ¹	17 ¹	
620						
1979-1975	16 ^E	16 ^E		16 ^E	16 ^E	
720						
1986	19	19		19	19	
1985-1980	16 ^E	16 ^E		16 ^E	16 ^E	
810						
1981	18	18	15 ^E	18	18	15 ^E
Altima						
2013				28 ^K	16 ^K	
2006-2002	26	17		26	17	
2001-1993	21	20		21	20	
Armada						
2013-2005	24	22		24	22	R12-B
Axxess						
1990	28	22	16	28	22	16
Cube						
2013-2009	20	20		20	20	R12-B
D21						
1994-1986	19	19		19	19	
Frontier						
2013-2005	24	18		24	18	
2004-1998	19	19		19	19	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Nissan						
GT-R						
2014-2013, 2011-2009				22	19 [*]	
Juke						
2013	24	14		24	14	R12-B
2012-2011	22	14		22	14	R12-B
Leaf						
2012-2011						R12-B
Maxima						
2008-2000	26	17		26	17	
1999-1995	22	21		22	21	
1994-1989	21	20		21	20	
1988-1985	19	19		19	19	
1984-1981	18	18	15 ^e	18	18	15 ^e
Micra						
1991-1987	18	18		18	18	
Multi						
1988-1986	19	19		19	19	
Murano						
2013-2009				26 ^v	16 ^v	R12-B
2008-2006				26 ^v	18 ^v	R14-B
2005-2003	26	19		26	19	R14-B
NV1500						
2013	11	11		21	21	
2012	21	21		21	21	
NV200						
2013	11	11		21	21	
NV2500						
2013	11	11		21	21	
2012	21	21		21	21	
NV3500						
2012	21	21		21	21	
NX						
1993-1992	20	19	20	20	19	20
1991	20	19		20	19	
Pathfinder						
2013	26 ^v	17 ^v		26 ^v	17 ^v	R14-D
2012-2005	24	18		24	18	R12-B
2004-1996	22	21	10	22	21	
1995-1987	19	19		19	19	
Pickup						
2000-1995	19	19		19	19	
Pulsar NX						
1990-1987	21	21		21	21	
1986	19	18		19	18	
Quest						
2013-2011	26	19		26	19	R12-B
2009-2004	26	18		26	18	R14-D
2002-1993	22	22	14 ^d	22	22	14 ^d
Rogue						
2013-2009	26	14		26	14	
Sentra						
2012-2007	26	16		26	16	
2006-2000	22	17		22	17	
1999-1995	21	19		21	19	
1994-1991	20	19		20	19	
1990-1987	19	18	19	19	18	19



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS						
MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Nissan						
Sentra						
1986-1985	18	18	16 ^E	18	18	16 ^E
1984-1982	18 ^E	18 ^E		18 ^E	18 ^E	
Stanza						
1992-1990	20	20		20	20	
1989-1987	19	19	20	19	19	20
1986-1982	18 ^E	18 ^E	18 ^E	18 ^E	18 ^E	18 ^E
Titan						
2013-2012	24	22		24	22	
2011-2004	24	24		24	24	
Van						
1988-1987	22	19	18 ^E	22	19	18 ^E
Versa						
2014-2012	Sedan	24	14	24	14	
2012	Hatchback	26	14	26	14	R14-D
2011-2007		26	14	26	14	R14-D
Xterra						
2012-2005		24	18	24	18	R12-B
2004-2000		19	19	14	19	14
Oldsmobile						
88						
1999-1992		22 ^N	22 ^N	22 ^N	22 ^N	
98						
1996-1991		22 ^N	22 ^N	22 ^N	22 ^N	
1990-1985		19 ^D	19 ^D	19 ^D	19 ^D	
1984-1963		18 ^D	18 ^D	18 ^D	18 ^D	
Achieva						
1998-1992		19 ^D	19 ^D	19 ^D	19 ^D	
Alero						
2004-1999		22	17	22	17	
Aurora						
2003-2001, 1999-1995		22 ^N	22 ^N	22 ^N	22 ^N	
Bravada						
2004-2002		22	22	16	22	16
2001-1996		20	20	14	20	14
1994-1991		16 ^D	16 ^D	14 ^D	16 ^D	14 ^D
Calais						
1987-1985		19 ^D	19 ^D	19 ^D	19 ^D	
Custom Cruiser						
1992-1991		22 ^N	22 ^N	16 ^D	22 ^N	16 ^D
1990-1971		18 ^D	18 ^D	16 ^D	18 ^D	16 ^D
Cutlass						
1999-1997		22	19	22	19	
1996-1995		20 ^N	20 ^N	20 ^N	20 ^N	
1987-1985, 1981-1978		18 ^D	18 ^D	18 ^D	18 ^D	
Cutlass Calais						
1991-1988		19 ^D	19 ^D	19 ^D	19 ^D	
Cutlass Ciera						
1996-1984		18 ^D	18 ^D	18 ^D	18 ^D	
Cutlass Cruiser						
1994-1987		18 ^D	18 ^D	16 ^D	18 ^D	16 ^D
Cutlass Supreme						
1997-1988		20 ^N	20 ^N	20 ^N	20 ^N	
1987-1985		18 ^D	18 ^D	18 ^D	18 ^D	
Delta 88						
1991-1986		19 ^D	19 ^D	19 ^D	19 ^D	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Oldsmobile						
Delta 88						
1985-1965	18 ^D	18 ^D	16 ^D	18 ^D	18 ^D	16 ^D
Firenza						
1988-1982	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D
Intrigue						
2002-1998	22	22		22	22	
LSS						
1999-1996	22 ^N	22 ^N		22 ^N	22 ^N	
Omega						
1984-1980	18 ^D	18 ^D		18 ^D	18 ^D	
Regency						
1998-1997	22	22		22	22	
Silhouette						
2004	24	24		24	24	
2003-1997	24	24	16	24	24	16
1996-1990	24 ^N	24 ^N	14 ^D	24 ^N	24 ^N	14 ^D
Starfire						
1980-1975	16 ^E	16 ^E		16 ^E	16 ^E	
Toronado						
1992-1986	19 ^D	19 ^D		19 ^D	19 ^D	
1985-1968	18 ^D	18 ^D		18 ^D	18 ^D	
Vista Cruiser						
1975-1964	18 ^D	18 ^D		18 ^D	18 ^D	
Plymouth						
Acclaim						
1995-1989	18 ^D	18 ^D		18 ^D	18 ^D	
Arrow Pickup						
1982-1979	17 ^I	17 ^I		17 ^I	17 ^I	
Breeze						
2000-1996	22	22		22	22	
Caravelle						
1988-1985	16 ^D	16 ^D		16 ^D	16 ^D	
Champ						
1982-1979	17 ^I	17 ^I		17 ^I	17 ^I	
Colt						
1994-1993	Base	22	18	22	18	
1994-1993	Vista	20	19	16	20	19
1992	Base	22	17	22	17	
1992	Vista	20	18	16	20	18
1991		20	17	20	17	16
1984-1979		17 ^I	17 ^I	17 ^I	17 ^I	
Conquest						
1986-1984	19 ^I	19 ^I	19 ^I	19 ^I	19 ^I	19 ^I
Fury						
1978-1974	18 ^D	18 ^D		18 ^D	18 ^D	
Gran Fury						
1989-1980	18 ^D	18 ^D		18 ^D	18 ^D	
Grand Voyager						
2000-1996	28	28	18	28	28	18
1995-1994	22	18	18	22	18	18
1993-1991	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D
1990-1988	16 ^D	16 ^D		16 ^D	16 ^D	
Horizon						
1990-1978	16 ^E	16 ^E	18 ^E	16 ^E	16 ^E	18 ^E
Laser						
1994-1992	20	20	19	20	20	19
Neon						
2001	22	19		22	19	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Plymouth						
Neon						
2000	22	19		22	19	
1999-1995	21	18		21	18	
PB100						
1980-1975	16 ^D	16 ^D		16 ^D	16 ^D	
PB150						
1983-1981	16 ^D	16 ^D		16 ^D	16 ^D	
PB200						
1980-1975	16 ^D	16 ^D		16 ^D	16 ^D	
PB250						
1983-1981	16 ^D	16 ^D		16 ^D	16 ^D	
PB300						
1980-1975	16 ^D	16 ^D		16 ^D	16 ^D	
PB350						
1983-1981	16 ^D	16 ^D		16 ^D	16 ^D	
Prowler						
2001-1999, 1997	17	19		17	19	
Reliant						
1989-1981	16 ^D	16 ^D	13 ^E	16 ^D	16 ^D	13 ^E
Sapporo						
1983-1978	17 ^I	17 ^I		17 ^I	17 ^I	
Scamp						
1983	16 ^E	16 ^E		16 ^E	16 ^E	
Sundance						
1994-1987	18 ^D	18 ^D		18 ^D	18 ^D	
Turismo						
1985-1983	16 ^E	16 ^E	18 ^E	16 ^E	16 ^E	18 ^E
Voyager						
2000-1996	28	28	18	28	28	18
1995-1993	22	18	18	22	18	18
1992-1991	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D
1990-1984	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D	16 ^D
1990-1984	18 ^D	18 ^D		18 ^D	18 ^D	
Pontiac						
6000						
1991-1984	18 ^D	18 ^D		18 ^D	18 ^D	
Aztek						
2005-2001	24	24		24	24	
Bonneville						
2005-2000	22	22		22	22	
1999-1992	22 ^N	22 ^N		22 ^N	22 ^N	
1991-1987	19 ^D	19 ^D		19 ^D	19 ^D	
1986-1968	18 ^D	18 ^D		18 ^D	18 ^D	
Catalina						
1981-1968	18 ^D	18 ^D		18 ^D	18 ^D	
Fiero						
1988-1984	18 ^D	18 ^D		18 ^D	18 ^D	
Firebird						
2002-1998	24	24		24	24	
1997-1993	24-R ^D	24-R ^D				
1992-1982	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D	18 ^D
1981-1970	18 ^D	18 ^D		18 ^D	18 ^D	
Firefly						
1991-1987	20 ^D	18 ^D	15 ^D	20 ^D	18 ^D	15 ^D
G3						
2009	22	18	13	22	18	13
G5						
2009-2007	22	17		22	17	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Pontiac						
G6						
2010-2009				24 ^H	21 ^H	
2008				24 ^F	21 ^F	
2007-2005				24 ^H	21 ^H	
G8						
2009-2008				26 ^H	15 ^H	
GTO						
2006-2004	22	20		22	20	
Grand Am						
2005-1998	22	17		22	17	
1997-1985	19 ^D	19 ^D		19 ^D	19 ^D	
1980-1978	18 ^D	18 ^D		18 ^D	18 ^D	
Grand Prix						
2008-1997	22	22		22	22	
1996-1988	20 ^N	20 ^N		20 ^N	20 ^N	
1987-1978	18 ^D	18 ^D		18 ^D	18 ^D	
J2000						
1983-1982	16 ^D	16 ^D		16 ^D	16 ^D	
J2000 Sunbird						
1985-1984	16 ^D	16 ^D		16 ^D	16 ^D	
LeMans						
1993-1988	18	18		18	18	
1981-1978	18 ^D	18 ^D		18 ^D	18 ^D	
Montana						
2008-2006	24	22		24	22	
2005	Base	24		24	24	
2005	SV6	22		24	22	
2004-1999	24	24		24	24	
Parisiene						
1986-1983	18 ^D	18 ^D		18 ^D	18 ^D	
Phnix						
1984-1980	18 ^D	18 ^D		18 ^D	18 ^D	
Safari						
1989-1987	18 ^D	18 ^D		18 ^D	18 ^D	
Solstice						
2009-2006	16	22		16	22	
Sunbird						
1994-1990	17 ^D	17 ^D		17 ^D	17 ^D	
1989-1986, 1980-1976	16 ^D	16 ^D		16 ^D	16 ^D	
Sunfire						
2005-1995	22	17		22	17	
T1000						
1987-1982	16 ^D	16 ^D		16 ^D	16 ^D	
1981	16 ^E	16 ^E		16 ^E	16 ^E	
Tempest						
1991-1987	18	18		18	18	
Torrent						
2009-2006	24	19	15	24	19	15
Trans Sport						
1998-1997	24	24	16	24	24	16
1996-1990	24 ^N	24 ^N	13 ^D	24 ^N	24 ^N	13 ^D
Vibe						
2010-2009	26	17		26	17	R11-A
2008-2003	21	18		21	18	R11-A
Porsche						
911						
2012-2011	22	22		22	22	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Porsche						
911						
2010-1998	22	22	22	22	22	22
1997-1995	15	18		15	18	
1994-1966	13	13	16			16
924						
1988-1987	19	19	19 ¹	19	19	19 ¹
1982-1977	20 ^P	20 ^P		20 ^P	20 ^P	
928						
1995-1993	19	19	19 ¹	19	19	19 ¹
1991-1981	20 ^P	20 ^P	19 ¹	20 ^P	20 ^P	19 ¹
944						
1991-1983	20 ^P	20 ^P	19 ¹	20 ^P	20 ^P	19 ¹
968						
1995-1992	19	19	19	19	19	19
Boxster						
2012-1998	22	22		22	22	
Cayenne						
2014-2008, 2006-2003				26 ^Q	26 ^Q	
Cayman						
2010-2006	22	22		22	22	
Panamera						
2012-2010	24	21		24	21	
Ram						
1500						
2013-2011	22	22		22	22	
2500						
2013-2011	22	22		22	22	
3500						
2013-2011	22	22		22	22	
4500						
2013-2011	22	22		22	22	
5500						
2013-2011	22	22		22	22	
C/V						
2013-2012	26	20	16	26	20	16
Dakota						
2011	21	21		21	21	
2011	22	22		22	22	
2010	22	22		22	22	
Ram Pickup						
2011-2010	22	22		22	22	
Saab						
9-2X						
2006-2005	22	17		22	17	R14-B
9-3						
2011-2008				22 ^H	22 ^H	
2007-2003	22	22		22	22	
2002-1999	21	21	20	21	21	20
9-3X						
2011-2010				22 ^H	22 ^H	
9-5						
2011	24	21		24	21	
2010-2005	22	22		22	22	
2004	22	22		22	22	R14-D
2003-1999	22	22		22	22	
9-7x						
2009-2005	22	22		22	22	R12-E



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES			
	Driver	Passenger	Rear	Driver	Passenger	Rear	
Saab							
900							
1998-1995		21	21	20	21	21	20
1994	Convertible	18	18		18	18	
1994	Hatchback	21	21	20	21	21	20
1993-1991	Convertible	16	16		16	16	
1993-1991	Sedan	18	18		18	18	
1990-1979		16	16		16	16	
9000							
1998-1986		21	21	21	21	21	21
Saturn							
Astra							
2009-2008					22 ^o	18 ^o	
Aura							
2009-2008					24 ^f	21 ^f	
2007					24 ^h	21 ^h	
Ion							
2007-2004		22	19		22	19	
Ion-1							
2005-2003		22	19		22	19	
Ion-2							
2007-2003		22	19		22	19	
Ion-3							
2007-2003		22	19		22	19	
L100							
2002-2001		19	19	13	19	19	13
L200							
2003-2001		19	19	13	19	19	13
L300							
2005		19	19	13	19	19	
2003-2001		19	19	13	19	19	13
L300-1							
2004		19	19	13	19	19	13
L300-2							
2004		19	19	13	19	19	13
L300-3							
2004		19	19	13	19	19	13
LS							
2000		19	19	13	19	19	13
LS1							
2000		19	19	13	19	19	13
LS2							
2000		19	19	13	19	19	13
LW1							
2000		19	19	13	19	19	13
LW2							
2000		19	19	13	19	19	13
LW200							
2003-2001		19	19	13	19	19	13
LW300							
2003-2001		19	19	13	19	19	13
Outlook							
2010-2007					24 ^f	21 ^f	
Relay-1							
2007		24	24	16	24	24	16
Relay-2							
2007-2005		24	24	16	24	24	16
Relay-3							
2007-2005		24	24	16	24	24	16



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Saturn						
SC						
1992-1991	22	21	15	22	21	15
SC1						
2002-1993	22	21	15	22	21	15
SC2						
2002-1993	22	21	15	22	21	15
SL						
2002-1991	22	21	15	22	21	15
SL1						
2002-1991	22	21	15	22	21	15
SL2						
2002-1991	22	21	15	22	21	15
SW1						
1999-1993	22	21	15	22	21	15
SW2						
2001-1993	22	21	15	22	21	15
Sky						
2010-2007	24	22	16	24	22	16
Vue						
2010-2008	24	16		24	16	
2007-2002	24	19	10	24	19	
Scion						
FR-S						
2013	22	20		22	20	
iQ						
2013-2012	24	18		24	18	R11-A
tC						
2013-2011	24	18		24	18	
2010-2005	26	16		26	16	
xA						
2006-2004	24	16		24	16	R12-A
xB						
2013-2008	22	20		22	20	R14-A
2006-2004	20	20		20	20	R12-A
xD						
2013-2008	26	14		26	14	
Smart						
Fortwo						
2013-2008				22 ^H	21 ^H	
Sterling						
825						
1988-1987	19	19		19	19	
827						
1991-1989	19	19	19	19	19	19
Subaru						
B9 Tribeca						
2007-2006	26 ^W	20		26 ^W	20	R14-B
BRZ						
2013	22	20		22	20	
Baja						
2006-2003	22	20		22	20	
Brat						
1987-1982	17 ^I	17 ^I		17 ^I	17 ^I	
1981-1978	13 ^E	13 ^E		13 ^E	13 ^E	
DL						
1985-1980	17 ^I	17 ^I		17 ^I	17 ^I	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Subaru						
Forester						
2014	26	17		26	17	R14-B
2013-2009	24	18		24	18	R14-B
2008-2004	22	19		22	19	R14-B
2003-1998	22	19		22	19	
GL						
1985-1980	17 ¹	17 ¹		17 ¹	17 ¹	
GLF						
1982-1980	17 ¹	17 ¹		17 ¹	17 ¹	
Impreza						
2013-2012	26	16		26	16	R12-B
2011-2008	24	16		24	16	R14-B
2007-2004	22	17		22	17	R14-B
2003-2002	20	17	15	20	17	15
2001-1993	21	18	15	21	18	15
Justy						
1994-1989	18	17	15	18	17	15
1988-1987	17 ¹	17 ¹	13 [®]	17 ¹	17 ¹	13 [®]
Legacy						
2013-2010	26	19		26	19	
2009-2005	24	18		24	18	R14-B
2004-2001	22	19	15	22	19	15
2000-1995	21	19	15	21	19	15
1994-1990	20	18	15	20	18	15
Outback						
2013-2010	26	19		26	19	R14-B
2009-2005	24	18		24	18	R14-B
2004-2001	22	19	15	22	19	15
2000	21	19	15	21	19	15
SVX						
1997	21	20		21	20	
1996-1992	22	20	18	22	20	18
Tribeca						
2013-2008	26 ^w	20		26 ^w	20	R14-B
XV Crosstrek						
2013	26	16		26	16	R12-B
Suzuki						
Aerio						
2007-2002	22	18		22	18	R12-B
Equator						
2012-2009	24	18		24	18	
Esteem						
2002-1995	20	18	14	20	18	14
Forenza						
2008-2004	22	19		22	19	
Grand Vitara						
2013-2006	19	19		19	19	R12-A
2005-1999	19	19	15	19	19	15
Kizashi						
2013-2010	24	20		24	20	
Reno						
2008-2005	22	19		22	19	
SJ410						
1985-1980	13	13		13	13	
SX4						
2013-2007	26	14		26	14	
Samurai						
1995-1986	13	13		13	13	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Suzuki						
Sidekick						
1998-1991	17	17	15	17	17	15
Swift						
2001-1995	20	19		20	19	
1994-1989	20	18	15	20	18	15
Verona						
2006-2004	22	20		22	20	
Vitara						
2004-1999	19	19	15	19	19	15
X-90						
1998-1996	17	18		17	18	
XL-7						
2009-2007	24	19	13	24	19	13
2006-2002	19	19	15	19	19	15
Toyota						
4Runner						
2013-2010	24	20		24	20	R12-A
2009-2003	22	20		22	20	
2002-1997	17	17	13	17	17	13
1996-1993	17	17		17	17	
Avalon						
2013	26	18		26	18	
2012-2005				26 ^u	20 ^u	
2004-2000	24	17		24	17	
1999-1995	21	19		21	19	
Camry						
2013	26	18		26	18	
2012	24 ^a	20 ^a		24 ^a	20 ^a	
2012	26 ^b	18 ^b		26 ^b	18 ^b	
2011-2007	24	20		24	20	
2006-2002	24	19		24	19	
2001-1997	21	19		21	19	
1996	21	19	14	21	19	
1995-1992	21	19		21	19	
1991-1987			15			15
Celica						
2005-2000	26	17		26	17	
1999-1994	21	20	20	21	20	20
Corolla						
2013-2009	26	16		26	16	
2008-2003	24	18		24	18	
2002-1993	20	18	16	20	18	16
Echo						
2005-2000	22	14		22	14	
FJ Cruiser						
2013-2007	14 ^y	14		14 ^y	14	
Highlander						
2013-2008	26	20		26	20	R12-A
2007-2001	22	19		22	19	R12-A
Land Cruiser						
2013, 2011-2008	24	22		24	22	R12-A
2007-2004	24	22	16	24	22	16
2003-1998	20	20		20	20	
1997-1993	18	18	16	18	18	16
MR2						
1995-1993	20	19		20	19	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Toyota						
MR2 Spyder						
2005-2000	20	19		20	19	
Matrix						
2013-2009	26	16		26	16	R11-A
2008-2003	21	18		21	18	R11-A
Paseo						
1999-1992	20	18		20	18	
Pickup						
1995-1993	17	17		17	17	
Previa						
1996-1991			17 ^k			17 ^k
Prius						
2013-2010	26	19		26	19	R16-A
2009-2004	26	18		26	18	R16-A
2003-2001	24	17		24	17	
Prius C						
2013-2012	28	14		28	14	
Prius V						
2013-2012	26	19		26	19	R16-A
RAV4						
2013	26	16		26	16	
2012-2006	24	16		24	16	R12-A
2005-2001	22	19		22	19	R12-A
2000-1996	20	18	14	20	18	14
Sequoia						
2013-2008			12	26 ^h	22 ^h	12
2007-2001	19	19	14	19	19	14
Sienna						
2013	28	20		28	20	R16-A
2012-2011	28	20	16	28	20	16
2010-2005	26	19	16	26	19	16
2004	26	19		26	19	R14-A
2003-1998	24	18	17	24	18	17
Solara						
2008-2004	24	19		24	19	
2003-1999	22	21		22	21	
Supra						
1998-1994	21	19	18	21	19	18
1993	21	18	18	21	18	18
T100						
1998-1993	19	19		19	19	
Tacoma						
2013	22	22		22	22	
2012-2005	22	21		22	21	
2004-1995	17	17		17	17	
Tercel						
1998-1991	18	18		18	18	
1981-1980	15 ^e	15 ^e	16 ^e	15 ^e	15 ^e	16 ^e
Tundra						
2013-2007				24 ^h	22 ^h	
2006-2000	19	19		19	19	
Venza						
2013-2009	26	22		26	22	R12-A
Yaris						
2012	Sedan	26	14	26	14	
2011-2007		26	14	26	14	R12-A



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Volkswagen						
Beetle						
2010-1998	21	21		21	21	
CC						
2012-2009				24 ^F	19 ^F	
Cabrio						
2002-1995	21	19		21	19	
Cabriolet						
1993-1985	16	16		16	16	
Corrado						
1994-1990	19	19	18	19	19	18
Dasher						
1981-1974	16	16	16	16	16	16
Eos						
2013-2007				24 ^F	19 ^F	
EuroVan						
2003-1999, 1997-1995	21	21	16	21	21	16
1994-1992	21	21	18	21	21	18
Fox						
1993-1987	18	18		18	18	
GTI						
2013				24 ^F	19 ^F	13
2012-2007				24 ^F	19 ^F	
2006	21	19		21	19	
Golf						
2013-2011				24 ^F	19 ^F	
2010, 2006- 2004	21	19		21	19	
2003-1993	21	19	13	21	19	13
1992-1985	16	16	16	16	16	16
Golf SportWagen						
2013				24 ^F	19 ^F	
Jetta						
2008-2007				24 ^F	20 ^F	
2006	21 ^A	19 ^A		21 ^A	19 ^A	
2006				24 ^{RF}	20 ^{RF}	
2005-1993	21	19		21	19	
1992-1980	16	16		16	16	
Passat						
2010-2006				24 ^F	19 ^F	
2005-2002				21 ^Q	21 ^Q	
2001-1991	21	21	15	21	21	15
1990	21	21	16	21	21	16
Passat CC						
2010-2009				24 ^F	19 ^F	
Phaeton						
2006-2004				24 ^Q	21 ^Q	
Quantum						
1988-1983	18	18	13	18	18	13
R32						
2008				24 ^F	19 ^F	
Rabbit						
2009-2006				24 ^F	19 ^F	
1984-1975	16	16		16	16	
Rabbit Pickup						
1983-1980	16	16		16	16	
Routan						
2012-2009	26	20		26	20	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Volkswagen						
Scirocco						
1988	19	18		19	18	
1987-1982	19	19	16	19	19	16
1981-1975	17	17	16	17	17	16
Tiguan						
2013-2009				24 ^F	21 ^F	
Touareg						
2013-2004				26 ^Q	26 ^Q	
Vanagon						
1991-1980	18	18	16	18	18	16
Volvo						
240						
1993-1990	17	17	13	17	17	13
242						
1984-1975	16	16	13	16	16	13
244						
1989-1985	17	17	13	17	17	13
1984-1975	16	16	13	16	16	13
245						
1989-1985	17	17	13	17	17	13
1984-1975	16	16	13	16	16	13
740						
1992-1985	20	20	13	20	20	13
760						
1990-1989	21	21	13	21	21	13
1988-1984	20	20		20	20	
780						
1991-1987	20	20		20	20	
850						
1997-1993	21	21	17	21	21	17
940						
1995-1991	20	20	13	20	20	13
960						
1997-1992	21	21		21	21	
C30						
2013-2012				26 ^F	20 ^F	
2011				26 ^H	20 ^H	
2010-2008				26 ^F	20 ^F	
C70						
2013-2007				26 ^F	19 ^F	
2005-1999	21	21		21	21	
1998	21 ^F	21		21	21	
S40						
2011				26 ^H	20 ^H	
2010-2005				26 ^F	20 ^F	
2004-1999	21	20		21	20	
S60						
2013				26	20	
2012				26 ^F	20 ^F	
2011				26 ^H	20 ^H	
2009-2005				24 ^H	22 ^H	
2004-2001	24	21		24	21	
S70						
2000-1998	21 ^S	21 ^S		21 ^S	21 ^S	
S80						
2013-2005				26 ^F	20 ^F	
2004-1999	24	22		24	22	



APPLICATION GUIDE FOR PASSENGER CARS & LIGHT TRUCKS

MAKE Model Group	STANDARD BLADES			BEAM BLADES		
	Driver	Passenger	Rear	Driver	Passenger	Rear
Volvo						
S90						
1998-1997	21	21		21	21	
V40						
2004-1999	21	20	16	21	20	16
V50						
2011				26 ^H	20 ^H	
2010-2005				26 ^F	20 ^F	
V70						
2010-2008				26 ^F	19 ^F	
2007-2005				24 ^H	22 ^H	
2004	24	22		24	22	
2003-2001	24	22	17	24	22	17
2000-1998	21 ^S	21 ^S	17	21 ^S	21 ^S	17
V90						
1998-1997	21	21	17	21	21	17
XC60						
2013-2012				26 ^F	20 ^F	
2011				26 ^H	20 ^H	
2010				26 ^F	20 ^F	
XC70						
2013-2012				26 ^F	20 ^F	
2011				26 ^H	20 ^H	
2010-2008				26 ^F	20 ^F	
2007-2005				26 ^H	22 ^H	
2004-2003	24	22		24	22	
XC90						
2013-2005				24 ^H	21 ^H	R14-D
2004-2003	24	22		24	22	
Yugo						
Cabrio						
1992-1990	16 ^G	16 ^G		16 ^G	16 ^G	
GV						
1992-1986	16 ^G	16 ^G		16 ^G	16 ^G	
GVL						
1989-1988	16 ^G	16 ^G		16 ^G	16 ^G	
GVS						
1988	16 ^G	16 ^G		16 ^G	16 ^G	
GVX						
1989-1988	16 ^G	16 ^G		16 ^G	16 ^G	



Footnote Glossary

Code	Description
A	Early
B	LATE
C	Two blades on rear doors
D	Arm Type: Side Pin 3/16 in.
E	Arm Type: Bayonet 7 X 2.5
F	Arm Type: Top Button
G	Arm Type: Bayonet 8 X 2.5
H	Arm Type: Pinch Tab
I	Arm Type: C S P
J	Arm Type: AM
K	Arm Type: 2 SC. Bayonet 7 X 2.5
L	Arm Type: Hook 9 X 3 (S)
M	Arm Type: See Comment
N	Arm Type: Side Pin 1/4 in.
O	Arm Type: Reverse Hook 9 X 4
P	Arm Type: Hook 8 X 3
Q	Arm Type: Side Lock Pin
R	Arm Type: offset hook
S	Arm Type: Hook 9 X 4 (S)
T	Arm Type: Bayonet 7 X 2,2
U	Arm Type: special
V	Arm Type: offset hook 9 X 3
W	Arm Type: Hook 12 X 4
X	Arm Type: LRB
Y	Center Position

